

**CLEANACRES MACHINERY**

**AIRTEC**

**INSTRUCTION AND PARTS  
MANUAL FOR THE  
FOLLOWING MODELS:**

185H18ECA

185H20ECA

185H24ECA

2500H18ECA

2500H20ECA

2500H24ECA

2000H18ECA

2000H20ECA

2000H24ECA

## I N D E X

| <u>PAGE NO</u> | <u>SECTION</u>   |
|----------------|--|
| 1 .. ..        | INTRODUCTION TO THE AIRTEC SPRAYER.                                    |
| 3 .. ..        | SAFETY PRECAUTIONS.  |
| 4 .. ..        | GUIDE TO EFFECTIVE CROP SPRAYING.                                      |
| 5 .. ..        | FITTING THE SPRAYER TO THE TRACTOR.                                    |
| 8 .. ..        | SPRAYER CONTROL BOX.   |
| 13 .. ..       | FILLING PROCEDURE.   |
| 14 .. ..       | USE OF CHEMICAL INDUCTION BOWL.  |
| 17 .. ..       | BOOM UNFOLDING AND FOLDING.  |
| 19 .. ..       | OPERATION OF TILT FOR BOOM INCLINATION.                                |
| 20 .. ..       | GENERAL GUIDE LINES FOR THE SELECTION OF SPRAY QUALITY.                |
| 22 .. ..       | SPRAY QUALITY GUIDE.   |
| 23 .. ..       | CALIBRATION PROCEDURE.   |
| 25 .. ..       | FILTRATION SYSTEM.   |
| 26 .. ..       | USE OF CONSTANT RECIRCULATING SYSTEM.                                  |
| 27 .. ..       | FLUSHING SPRAYER THROUGH WITH FRESH WATER WHEN SPRAY<br>TANK IS EMPTY. |
| 29 .. ..       | FLUSHING OUT THE SPRAYLINES AND PLUMBING WHEN CHEMICAL<br>IN TANK.     |
| 30 .. ..       | LIQUID FERTILIZER.   |

## I N D E X

| <u>PAGE NO</u> | <u>SECTION</u>                        |
|----------------|---------------------------------------|
| 31 .. ..       | PRE AND POST SPRAYING CHECKS.         |
| 35 .. ..       | ROUTINE MAINTENANCE.                  |
| 37 .. ..       | FROST PROTECTION PRECAUTION.          |
| 38 .. ..       | FAULT FINDING.                        |
| 45 .. ..       | LEGAL REQUIREMENTS.                   |
| 46 .. ..       | APPENDIX 1 JET CHART.                 |
| 47 .. ..       | CONTROL BOX SPARES.                   |
| 49 .. ..       | LIQUID LINE SPARES.                   |
| 51 .. ..       | AIR LINE SPARES.                      |
| 53 .. ..       | SELF FILL SPARES.                     |
| 55 .. ..       | DISTRIBUTION MANIFOLD SPARES.         |
| 57 .. ..       | BOOM SPARES.                          |
| 60 .. ..       | AIRTEC NOZZLE.                        |
| 62 .. ..       | BACK FRAME AND CENTRE SECTION SPARES. |
| 65 .. ..       | BACK FRAME AND PANTOGRAPH ARM.        |
| 67 .. ..       | LIQUID MANIFOLD.                      |
| 69 .. ..       | INCORPORATOR CONTROL ASSEMBLY.        |
| 71 .. ..       | USEFUL CONTACTS.                      |

## INTRODUCTION TO THE AIRTEC SPRAYER.

THE CLEANACRES AIRTEC SPRAYER HAS BEEN DESIGNED TO ALLOW LOW VOLUME APPLICATION WHEN APPLYING CHEMICALS, WHILE AT THE SAME TIME DRAMATICALLY REDUCING SPRAY DRIFT AND BLOCKAGES. HOWEVER A FEW BLOCKED NOZZLES MAY BE EXPERIENCED IN THE FIRST WEEK OF OPERATION, THIS IS DUE TO ENGINEERING SWARTH WITHIN THE SYSTEM THAT IS VERY DIFFICULT TO REMOVE UNTIL CHEMICAL HAS BEEN USED IN THE SPRAYER.

WITH THE KNOWLEDGE AND ADVICE OF YOUR AGRONOMIST, WE ARE CONFIDENT THAT GREAT BENEFITS WILL COME FROM THE CORRECT OPERATION OF THIS SPRAYER.

### GENERAL LAYOUT

LIQUID IS DRAWN FROM THE TANK, THROUGH A SUCTION FILTER, TO THE DIAPHRAGM PUMP. ON THE PRESSURE SIDE OF THE PUMP THE LIQUID IS PUMPED THROUGH A FLUSHING PRESSURE FILTER AND INTO THE LIQUID DISTRIBUTION MANIFOLD, ON WHICH ARE MOUNTED THE INDIVIDUAL BOOM SECTION BALL VALVES.

WHEN THE SPRAYLINE CONTROLS ARE IN THE 'ON' POSITION, THE LIQUID IS PASSED THROUGH THE OPEN BALL VALVES TO THE SPRAYLINES, ON WHICH ARE MOUNTED THE AIRTEC NOZZLE ASSEMBLIES. THE SPRAYLINES ARE FITTED WITH A CONSTANT RECIRCULATING SYSTEM(C.R.S). THIS IS A RETURN TO TANK PIPE FITTED ON THE OUTER END OF THE SPRAYLINES THAT ALLOWS AGITATION TO TAKE PLACE WITHIN THE SPRAYLINES, AS WELL AS IN THE TANK. THE C.R.S. ENSURES THAT WHEN LOW VOLUME IS BEING USED, POWDERS DO NOT SETTLE OUT IN THE SPRAYLINE, THUS BECOMING A POTENTIAL BLOCKAGE PROBLEM. ALL LIQUID FROM THE CRS IS RETURNED

TO THE SPRAYER TANK TO PROVIDE ADDITIONAL AGITATION. WHEN THE SPRAYLINE CONTROLS ARE IN THE 'OFF' POSITION THE LIQUID PASSES THROUGH THE OPPOSITE SIDE OF THE BALL VALVES, THROUGH THROTTLE VALVES AND BACK INTO THE TANK TO PROVIDE FURTHER AGITATION. THE THROTTLE VALVES ENSURE THAT WHEN INDIVIDUAL SECTIONS ARE TURNED OFF THE LIQUID PRESSURE IN THE REMAINING SECTIONS STAYS CONSTANT.

THE AIR SYSTEM ON THE SPRAYER USES A HIGH VOLUME, LIQUID COOLED, ROTARY COMPRESSOR TO SUPPLY AIRFLOW TO THE BOOM SECTIONS. AIR IS FED FROM THE COMPRESSOR INTO THE AIR DISTRIBUTION MANIFOLD. FROM HERE THE AIR PASSES THROUGH ELECTRIC SOLENOIDS TO THE INDIVIDUAL BOOM SECTIONS. AIR IS FED TO THE AIRTEC NOZZLE THROUGH A SEPARATE SET OF PIPELINES, THE AIR AND THE LIQUID IS THEN MIXED IN THE NOZZLE TO PROVIDE THE AIR INCLUDED DROPLET FORMATION.

LIQUID PRESSURE IS CONTROLLED BY THE USE OF A MOTORIZED ELECTRIC BALL VALVE, AND AIR PRESSURE BY A MOTORIZED BUTTERFLY VALVE.

APPLICATION RATES CAN BE ALTERED BY CHANGING THE TRACTOR'S FORWARD SPEED AND/OR USING THE IN-CAB CONTROLS TO VARY AIR AND LIQUID PRESSURE. SPRAY QUALITY CAN BE ALTERED BY CHANGING THE RATIO BETWEEN THE LIQUID AND AIR PRESSURE.

## SAFETY PRECAUTIONS.

- ALWAYS PROP THE BOOM BEFORE WORKING UNDERNEATH IT  
IN CASE OF MECHANICAL OR HYDRAULIC FAILURE.
- ALWAYS 1. CHOCK THE WHEELS TO PREVENT IT MOVING, TURNING  
THE ENGINE OFF AND DISENGAGING THE PTO BEFORE WORKING  
BETWEEN THE TRACTOR AND THE SPRAYER.
2. FOR THREE POINT LINKAGE MOUNTED MACHINES THE SPRAYER  
SHOULD BE PROPPED TO PREVENT IT DROPPING ON THE HYDRAULIC  
LINKAGE. FOR TRAILED MACHINES THE TRAILED WHEELS SHOULD  
ALSO BE CHOCKED.
- ALWAYS FIRMLY SECURE THE BOOMS BEFORE TRAVELLING.
- NEVER ALLOW CHILDREN TO PLAY NEAR THE SPRAYER.
- ALWAYS WEAR PROTECTIVE CLOTHING, AS SPECIFIED ON THE CHEMICAL  
CONTAINER LABEL, WHEN HANDLING CHEMICALS. CALCULATE  
AND CAREFULLY MEASURE IN THE AMOUNT OF CHEMICAL REQUIRED.
- NEVER ADD CHEMICALS TO AN EMPTY SPRAY TANK, ALWAYS TO A HALF  
FULL TANK, THEN FILL UP AND AGITATE GENTLY TO MIX. RINSE  
CHEMICAL CONTAINERS INTO THE TANK AND DISPOSE OF THEM  
SAFELY.
- ALWAYS WASH DOWN ANY SPILLS AND STORE UNUSED CONTAINERS SAFELY.
- DO NOT STORE PROTECTIVE CLOTHING IN THE TRACTOR CAB, ALWAYS  
PLACE IT IN THE LOCKER PROVIDED.
- ALWAYS WASH HANDS BEFORE SMOKING, EATING, OR DRINKING.

## GUIDE TO EFFECTIVE CROP SPRAYING.

FOR EFFECTIVE CROP SPRAYING WITH MODERN EXPENSIVE AGROCHEMICALS IT IS VERY IMPORTANT TO SPRAY ACCURATELY.

### SPRAYING OBJECTIVES:

ALWAYS AIM TO SPRAY THE RECOMMENDED CHEMICAL RATE SAFELY AND EFFECTIVELY BY ENSURING THAT THE CORRECT VOLUME OF CHEMICAL REACHES THE INTENDED TARGET AND THAT AS LITTLE AS POSSIBLE DRIFTS OR RUNS OFF AND CONSEQUENTLY FAILS TO REACH THE TARGET.

AIM TO CARRY OUT THE OPERATION QUICKLY AND COST EFFECTIVELY BY USING THE LOWEST SPRAY VOLUME COMPATIBLE WITH CHEMICAL AND CONDITIONS AND A FORWARD SPEED WITHOUT EXCESSIVE BOOM BOUNCE, DRIFT OR INEFFICIENT APPLICATION.

THERE ARE FOUR KEY ASPECTS TO ACCURATE, TROUBLE FREE SPRAYING:


- PREPARATION
- AIRTEC SETTING SELECTION
- CALIBRATION
- GOOD FIELD WORK

THE NEXT SECTION OF THIS SPRAYER MANUAL GIVES FURTHER INFORMATION ON EACH OF THESE AREAS.

## FITTING THE SPRAYER TO THE TRACTOR.

THIS MANUAL COVERS THREE TYPES OF SPRAYER IN THE CLEANACRES AIRTEC RANGE. PLEASE REFER TO THE APPROPRIATE SECTION RELATING TO YOUR PARTICULAR SPRAYER.

### 1. THREE POINT LINKAGE MOUNTED MACHINES

 **WARNING** ALWAYS PROP THE SPRAYER AND CHOCK THE TRACTOR WHEELS, AND STOP THE TRACTOR ENGINE BEFORE WORKING BETWEEN TRACTOR AND SPRAYER. FIT THE SPRAYER TO THE TRACTORS THREE POINT LINKAGE AS FOLLOWS:-  
CONNECT LEFT HAND THEN RIGHT HAND LINKAGE, AND THEN TOP LINK WHILST SPRAYER IS STILL ON THE PARKING LEGS. CONNECT P.T.O. AND ELECTRICS.  
RAISE THE SPRAYER AND REMOVE OR STOW THE PARKING LEGS.  
LOWER LINK CHAINS OR STABILIZERS SHOULD BE FITTED TO IMPROVE THE SPRAYER'S HANDLING UNDER ROUGH CONDITIONS.

### 2. TRAILED SPRAYERS.

THESE MACHINES ARE DESIGNED TO BE TOWED ON THE TRACTOR'S PICK UP HITCH. IF THE SPRAYER IS TO BE TOWED USING A CLEVIS DRAWBAR THEN A SPECIAL REDUCING BUSH MUST BE INSERTED INTO THE DRAWBAR HOLE ON THE SPRAYER TO REDUCE THE SIZE OF THIS HOLE DOWN TO THE SIZE OF THE DRAW PIN. IF THIS REDUCING BUSH IS NOT USED THEN SERIOUS DAMAGE TO THE SPRAYER OR TRACTOR COULD RESULT.

TO ATTACH THE SPRAYER TO THE TRACTOR THE DRAWBAR JACK SHOULD BE SET TO A SUITABLE HEIGHT FOR THE TRACTOR HITCH. THE SPRAYER SHOULD THEN BE HITCHED TO THE TRACTOR IN THE CONVENTIONAL WAY. ONCE THE SPRAYER IS HITCHED TO THE TRACTOR THE JACK SHOULD BE WOUND FULLY UP AND TRANSFERRED TO ITS TRANSPORT POSITION.





WARNING WHEN TOWING THE SPRAYER WITH A DRAW PIN, ALWAYS ENSURE THAT A LYNCH PIN IS INSERTED THROUGH THE HOLE IN THE BOTTOM OF THE PIN TO PREVENT THE PIN FROM JUMPING OUT.

IN ORDER TO KEEP THE SPRAYER LEVEL FORE AND AFT, IT MAY BE NECESSARY TO ADJUST THE HEIGHT OF THE WHEELS. BEFORE CARRYING OUT THIS OPERATION ALWAYS ENSURE THAT THE SPRAYER IS ON FIRM, LEVEL GROUND AND THAT THE WHEELS ARE CHOCKED. JACKING UP ONE SIDE OF THE SPRAYER AT A TIME, REMOVE THE WHEEL HEIGHT ADJUSTMENT PIN AND ADJUST THE WHEEL HEIGHT TO SUIT REQUIREMENTS. RE-INSERT THE PIN AND REPLACE THE SAFETY LYNCH PIN. REPEAT THIS PROCESS ON THE OTHER SIDE OF THE SPRAYER.

### 3. MB TRAC MOUNTED MACHINES.

THESE ARE SUPPLIED WITH THEIR OWN, CUSTOM MADE SUB-FRAME, WHICH BOLTS DIRECTLY ONTO THE MB.TRAC CHASSIS.

ONCE FITTED, THE SUB-FRAME CAN BE LEFT ON, AS IT DOES NOT INTERFERE WITH ANY OF THE TRACTOR FUNCTIONS.

TO MOUNT THE SKID UNIT SPRAYER ONTO THE SUB-FRAME, IT IS NECESSARY TO RAISE THE SPRAYER UP ON ITS DEMOUNT LEGS UNTIL THERE IS AT LEAST ONE INCH OF CLEARANCE BETWEEN THE BOTTOM TANK FITTINGS OF THE SPRAYER AND THE TRACTOR REAR MUD-GUARDS. AFTER ENSURING THAT NO CABLES OR PIPES CAN BE TRAPPED, REVERSE THE TRACTOR UNDER THE SPRAYER SO THAT THE BOTTOM RUNNERS OF THE SPRAYER ARE IN LINE WITH THE BEARERS OF THE SUB-FRAME.

JUST BEFORE THE FRONT LOCATING HOOKS ON THE SPRAYER REACH THE FRONT CROSS MEMBER ON THE SUB-FRAME, LOWER THE SPRAYER ON THE DEMOUNT LEGS SO THAT THE FRONT OF THE RUNNERS ON THE SPRAYER ARE JUST RESTING ON THE SUB-FRAME, AND THE BACK OF THE RUNNERS ARE

JUST CLEAR OF THE SUB-FRAME. CONTINUE REVERSING UNDER THE MACHINE UNTIL THE FRONT LOCATING HOOKS ARE FIRMLY LOCATED UNDER THE FRONT CROSS-MEMBER. NOW LOWER THE WHOLE SPRAYER ONTO THE SUB-FRAME AND INSERT THE REAR RETAINING PINS.

THE DEMOUNT LEGS CAN NOW BE REMOVED AND STORED IN A SAFE PLACE UNTIL THEY ARE NEXT NEEDED.

#### CONNECTION TO TRACTOR OF HYDRAULIC SERVICES

CONNECT THE HYDRAULIC PIPES FROM THE SPRAYERS HYDRAULIC VALVES TO THE TRACTORS HYDRAULIC SERVICES AS FOLLOWS:

RED - PRESSURE FROM TRACTOR SPOOL.

GREEN - RETURN THROUGH OPEN LINE RETURN TO OIL TANK.



**CAUTION:** IF THE HYDRAULIC PIPES ARE INCORRECTLY FITTED, DAMAGE MAY OCCUR.

THE MINIMUM TRACTOR SPOOL REQUIREMENT IS ONE SINGLE ACTING, HOWEVER, IF A FRONT TANK, FITTED WITH A HYDRAULICALLY DRIVEN CENTRIFUGAL PUMP IS TO BE USED, THEN TWO SINGLE ACTING VALVES WITH AN UNRESTRICTED RETURN TO TANK FOR THE FRONT TANK RETURN PIPE WILL BE REQUIRED.

FRONT TANK HYDRAULIC PIPES WILL BE COLOUR CODED IN THE SAME MANNER AS THE SPRAYER.

#### CONNECTION TO TRACTOR OF ELECTRICAL SERVICES.

THE ELECTRICAL PLUGS AND SOCKETS ARE COLOUR CODED TO ENSURE THE CORRECT PLUG GOES INTO THE CORRECT SOCKET. BEFORE CONNECTING ENSURE ALL ELECTRICAL SERVICES ARE SWITCHED OFF.


## SPRAYER CONTROL BOX.

CLEANACRES AIRTEC SPRAYERS ARE ALL FITTED WITH IN-CAB CONTROLS FOR OPERATION OF BOOM SECTION CONTROL, PRESSURE ADJUSTMENT AND BOOM HYDRAULIC FUNCTIONS FOR YOUR SAFETY AND COMFORT. THE FOLLOWING STEPS SHOULD BE FOLLOWED WHEN INSTALLING CONTROLS IN THE CAB:

A. MOUNT THE CONTROL BOX WITHIN EASY REACH AND VISION FROM THE TRACTOR SEAT, IDEALLY TO THE RIGHT OF THE STEERING WHEEL. ENSURE THAT THE ELECTRIC CABLES HAVE AN UNRESTRICTED RUN THROUGH THE REAR OF THE CAB, PREFERABLY THROUGH THE FLOOR OF THE CAB TO ALLOW THE WINDOWS TO SHUT WHEN SPRAYING. THE PLATE CARRYING THE FOUR SEVEN-PIN SOCKETS SHOULD BE MOUNTED ON THE OUTSIDE OF THE CAB IN A POSITION WHERE IT WILL NOT FOUL ANY OF THE TRACTORS EXTERNAL SERVICES. THE FOUR PLUGS FROM THE SPRAYER SHOULD THEN BE CONNECTED UP TO THE SOCKETS, WITH SUFFICIENT LENGTH OF CABLE TO ALLOW FOR RAISING AND LOWERING OR TURNING THE SPRAYER.

B. TAKE AN ELECTRICAL SUPPLY TO THE CONTROL BOX FROM THE TRACTOR'S FUSE BOX OR DIRECTLY FROM THE BATTERY. MAKE SURE THAT THE SUPPLY CABLE IS ROUTED SO THAT IT WILL NOT BECOME PINCHED AT ANY TIME OR GET CAUGHT UP IN ANY MOVING PARTS.

CONTROL BOX FIGURE 1



## HYDRAULIC CONTROLS

1. HYDRAULIC ON/OFF.
2. MAINFOLD SWITCH.
3. RAISE/LOWER SWITCH.
4. RIGHT HAND FLIP OVER.
5. LEFT HAND FLIP OVER.
6. BOOM TILT.

## SPRAYER CONTROLS

7. SECTION WARNING LIGHTS.
8. INDIVIDUAL SECTION CONTROLS.
9. BOOM MASTER CONTROL.
10. FRONT TANK CONTROL.
11. AIR PRESSURE CONTROL.
12. LIQUID PRESSURE CONTROL.
13. FUSE HOLDERS.

1. HYDRAULIC ON/OFF: THIS SWITCH MUST BE ON BEFORE ANY OF THE ELECTRO-HYDRAULIC SERVICES ON THE SPRAYER WILL WORK.

2. MAINFOLD SWITCH: THIS SWITCH CONTROLS THE FOLDING AND UNFOLDING OF THE MAIN BOOM SECTIONS.

3. RAISE/LOWER SWITCH: THIS SWITCH CONTROLS THE RAISING AND LOWERING OF THE BOOMS ON THE SPRAYER.

4. RIGHT HAND FLIP OVER: THIS SWITCH CONTROLS THE FOLDING AND UNFOLDING OF THE RIGHT HAND OUTER SECTION OF THE BOOM.

5. LEFT HAND FLIPOVER: THIS SWITCH CONTROLS THE FOLDING AND UNFOLDING OF THE LEFT HAND OUTER SECTION OF THE BOOM.

6. BOOM TILT: THIS SWITCH CONTROLS THE BOOM TILT, WHICH ALLOWS THE BOOM TO REMAIN PARALLEL TO THE GROUND, EVEN WHEN WORKING ON SLOPING GROUND.

7. SECTION WARNING LIGHTS: THESE WARNING LIGHTS ARE ON WHEN THE APPROPRIATE SECTION IS SPRAYING.

8. INDIVIDUAL SECTION CONTROLS: THESE ARE USED FOR OPERATING IN SHORT WORK TO ISOLATE INDIVIDUAL BOOM SECTIONS. THE SWITCHES CONTROL BOTH THE AIR AND LIQUID LINES.

9. BOOM MASTER CONTROL: THIS SWITCH SHUTS AND OPENS ALL FOUR BOOM SECTIONS WHEN TURNING AT THE HEADLANDS ETC.. SPRAYLINES ARE ON WHEN THE RED LIGHT IS GLOWING. THIS SWITCH ALSO SHUTS OFF THE AIR SUPPLY TO THE AIR LINES.

10. FRONT TANK SWITCH: THIS IS USED TO TRANSFER LIQUID FROM THE FRONT TO THE REAR TANK (WHERE APPLICABLE). WHEN THE GREEN LIGHT IS GLOWING, LIQUID IS BEING TRANSFERRED. WHEN THE GREEN LIGHT IS OFF THE LIQUID IS AGITATING AND NOT BEING TRANSFERRED.

11. & 12. AIR & LIQUID PRESSURE CONTROLS: THESE INCREASE OR DECREASE THE AIR AND LIQUID PRESSURE, PUSH THE SWITCH TO THE RIGHT AND PRESSURE WILL INCREASE, TO THE LEFT AND IT WILL DECREASE. THESE SWITCHES OPERATE BUTTERFLY VALVES ON THE AIR AND LIQUID MANIFOLDS. BECAUSE THE VALVES CAN OPERATE THROUGH 360 DEGREES THEY CAN GO OVER CENTRE, SO THAT THE PRESSURE WILL DROP WHEN IT SHOULD BE RISING AND VICE VERSA. SHOULD THIS HAPPEN, SIMPLY PUSH THE SWITCH IN THE DIRECTION REQUIRED, THE PRESSURE WILL INITIALLY MOVE IN THE WRONG DIRECTION, THE VALVE WILL THEN GO BACK OVER CENTRE AND THE PRESSURE WILL THEN MOVE IN THE RIGHT DIRECTION.


#### PRESSURE GAUGES.

-----

**⚠ IMPORTANT:** AT THE START OF EACH DAY'S SPRAYING, PARTIALLY FILL THE SPRAY TANK WITH WATER, SET THE MACHINE TO SPRAY AND OPEN THE TAP ON THE BOTTOM OF THE LIQUID PRESSURE GAUGE. WAIT FOR ALL OF THE AIR TO BE EXPELLED (WATER WILL FLOW UNDER PRESSURE FROM THE DRAIN PIPE) AND THEN CLOSE THE TAP. THIS WILL ENSURE NO AIR IS TRAPPED AND THAT THE CORRECT LIQUID PRESSURE READING IS GIVEN. THIS TAP MUST ALSO BE OPENED WHEN FLUSHING OUT TO PREVENT RESIDUE BUILD UP.

FIGURE 2

# VALVE LAYOUT (MB TRAC)



### FILLING PROCEDURE.


REFER TO FIGURE 2.

THE AIRTEC SPRAYER IS FITTED WITH A SPRAYER SELF-FILL AND A CHEMICAL INDUCTION BOWL. THE FOLLOWING PROCEDURE SHOULD BE FOLLOWED WHEN FILLING THE SPRAYER.

A. DISENGAGE P.T.O.

B. USING A CLEAN WATER SOURCE, CONNECT THE SELF FILL HOSE TO THE MALE CAMLOCK COUPLING ON THE SUCTION VALVE, CHECKING FIRST THAT A RUBBER SEAL IS FITTED IN THE FEMALE CAMLOCK COUPLING ON THE END OF THE SELF-FILL HOSE. ROTATE THE SUCTION VALVE TO THE 'SELF FILL' POSITION.

C. SET THE PRESSURE VALVE TO THE FILL POSITION AND IMMERSE THE FILTER END OF THE SELF FILL HOSE INTO THE WATER SOURCE.


D. CHECK THAT THE SPRAYER CONTROLS ON THE CONTROL BOX ARE SWITCHED OFF AND ENGAGE THE P.T.O. GRADUALLY INCREASE THE P.T.O. SPEED TO 540 R.P.M.  CAUTION DO NOT ENGAGE PTO IMMEDIATELY AT FULL SPEED, OTHERWISE EXPENSIVE DAMAGE MAY OCCUR TO THE PUMP AND COUPLINGS.  
THE SPRAYER WILL NOW BE SELF FILLING.

E. ALLOW THE SPRAYER TO FILL TO HALF ITS CAPACITY, OR HALF OF THE AMOUNT OF WATER REQUIRED. TURN THE SUCTION VALVE TO THE "FROM TANK" POSITION.



## USE OF CHEMICAL INDUCTION BOWL.

NOTE: IF SPRAYER REQUIRES CALIBRATING THIS MUST BE DONE FIRST  
USING CLEAN WATER (REFER TO PAGE 23).

 WARNING: BEFORE HANDLING ANY PESTICIDE CONTAINER, ENSURE  
THAT THE CORRECT PROTECTIVE CLOTHING IS WORN, AS SPECIFIED ON THE  
CHEMICAL CONTAINER LABEL.

IT IS RECOMMENDED THAT YOU FAMILIARIZE YOURSELF WITH THE SYSTEM  
USING WATER BEFORE USING CHEMICAL.

THE CHEMICAL INDUCTION BOWL IS FITTED TO THE SUCTION SIDE OF  
THE SELF FILLING SYSTEM. CHEMICAL IS DRAWN FROM THE INDUCTION  
BOWL AND IS MIXED WITH WATER DRAWN FROM THE TANK BEFORE PASSING  
THROUGH THE PUMP. THIS PREVENTS NEAT CHEMICAL FROM COMING INTO  
CONTACT WITH THE PUMP DIAPHRAGMS.

IT IS POSSIBLE TO INDUCT CHEMICAL BOTH WHEN THE SPRAYER IS SELF  
FILLING WITH WATER, AND WHEN THE CONTENTS OF THE TANK ARE BEING  
AGITATED. CARE SHOULD BE TAKEN TO ENSURE THAT THERE IS ENOUGH  
SPACE REMAINING IN THE TANK TO ACCEPT THE CHEMICAL.

REFER TO FIGURE 2.  
-----


1. THIS VALVE CONTROLS THE FLOW OF WATER TO THE INDUCTION  
BOWL RINSING JETS.
2. THIS VALVE CONTROLS THE FLOW OF CHEMICAL OUT OF THE INDUCTION  
BOWL.

WITH THE VALVES 1 & 2 BOTH CLOSED, POUR THE REQUIRED AMOUNT OF CHEMICAL INTO THE CHEMICAL INDUCTION BOWL. OPEN VALVE 2 SO THAT THE CHEMICAL IS TRANSFERRED TO THE TANK. IT IS IMPORTANT TO CLOSE VALVE 2 AS SOON AS THE INDUCTION BOWL IS EMPTY. IF IT IS LEFT OPEN, AIR WILL BE DRAWN INTO THE SYSTEM, CAUSING FOAMING IN THE TANK.

**NOTE:** OPERATORS MAY FIND THAT THERE IS INSUFFICIENT SUCTION TO EMPTY THE INDUCTION BOWL. IF THIS IS THE CASE THEN PARTIALLY CLOSE THE SUCTION VALVE NEVER CLOSE THIS VALVE FULLY, AS DAMAGE TO THE PUMP MAY OCCUR.

WHEN ALL OF THE LIQUID HAS BEEN ADDED THE BOWL CAN BE RINSED OUT BY TURNING ON VALVE 1 SO THAT WATER IS DELIVERED TO THE BOWL RINSING JETS.

HAVING FINISHED ADDING THE CHEMICAL, TURN OFF VALVE 1. AND THEN TURN OFF VALVE 2 WHEN THE INDUCTION BOWL IS EMPTY. FINALLY TURN THE SUCTION VALVE TO "SELF FILL" AND CONTINUE TO FILL THE TANK UNTIL THE DESIRED AMOUNT OF WATER IS IN THE TANK.

 **IMPORTANT:** THE SIGHT GAUGES WILL NOT BE ACCURATE UNLESS THE SPRAYER IS PARKED ON PERFECTLY LEVEL GROUND. FOR GREATER ACCURACY CLEANACRES MACHINERY OFFER A HIGH OUTPUT FLOW METER FOR INSTALLATION IN THE SUCTION PIPE.

## POWDER FORMULATIONS

THE INDUCTION BOWL MAY BE USED AS A CONTAINER TO CREAM

POWDERS AS FOLLOWS:-

TURN VALVE 2 OFF AND OPEN VALVE 1 TO ADD WATER TO THE INDUCTION BOWL. CLOSE VALVE 1 WHEN THERE IS SUFFICIENT WATER IN THE INDUCTION BOWL TO MIX THE POWDERS. AFTER MIXING OPEN VALVE 2 TO EMPTY THE INDUCTION BOWL - REPEAT AS NECESSARY.

## ALTERNATIVE METHOD FOR POWDERS.

PART FILL THE INDUCTION BOWL WITH WATER. NEXT PARTLY OPEN VALVE 2 SO THAT THE WATER LEVEL IN THE INDUCTION BOWL REMAINS CONSTANT I.E. THE RINSING JETS ARE ADDING WATER AS FAST AS IT IS BEING REMOVED. POWDERS MAY NOW BE ADDED DIRECTLY TO THE BOWL. MOST CHEMICALS WILL BE MIXED WITH THE WATER AS THEY ARE SUCKED INTO THE SPRAYER TANK. A PERIOD OF AGITATION IN THE MAIN TANK AS THE REST OF THE WATER IS BEING ADDED WILL COMPLETE THE MIXING PROCESS. ALWAYS READ THE LABEL BEFORE ADDING POWDER TO THE TANK, AS SOME PRODUCTS SHOULD NOT BE PRE-CREAMED, AND SHOULD BE ADDED DIRECT INTO THE SPRAYER TANK.

## OPERATING TIPS.

1. IF IT IS NECESSARY TO STOP THE PUMP WHILE USING THE CHEMICAL INDUCTION BOWL ENSURE VALVE 2 IS CLOSED FIRST. THIS PREVENTS WATER RUNNING BACK INTO THE INDUCTION BOWL FROM THE TANK.
2. IF CHEMICAL IS PRONE TO FOAM USE THE CHEMICAL BOWL AT THE MINIMUM P.T.O. SPEED POSSIBLE.


### BOOM UNFOLDING AND FOLDING.

ELECTRO HYDRAULIC CONTROLS ARE USED ON ALL OF THE BOOM FUNCTIONS. THIS MEANS THAT ALL BOOM FUNCTIONS CAN BE CONTROLLED FROM THE CAB USING THE CONTROL BOX AND ONE SPOOL VALVE. IN ORDER TO UNFOLD THE BOOMS, FOLLOW THE FOLLOWING PROCEDURE REFERRING TO FIGURE 1.

 **WARNING** ENSURE THAT SPRAYER IS WELL AWAY FROM OVERHEAD POWER CABLES.

- A. TURN ON THE HYDRAULIC ON/OFF SWITCH (NUMBER 1) ON THE CONTROL BOX.
- B. PLACE THE APPROPRIATE SPOOL VALVE IN THE CONSTANT FLOW POSITION.
- C. USING THE RAISE/LOWER SWITCH (NUMBER 3) RAISE THE BOOMS OUT OF THE BOOM RESTS UNTIL THE BOOMS ARE IN THE FULLY RAISED POSITION.
- D. USING THE MANIFOLD SWITCH (NUMBER 2) OPEN OUT THE BOOMS UNTIL BOTH SIDES ARE IN THE FULLY UNFOLDED POSITION.
- E. USING THE OUTER SECTION, FLIP OVER SWITCHES (NUMBERS 4 + 5) FIRST UNFOLD ONE OUTER SECTION AND THEN THE OTHER. ALWAYS ENSURE THAT BOTH OUTER SECTIONS ARE FULLY UNFOLDED.

THE TWO OUTER SECTIONS CAN BE UNFOLDED SIMULTANEOUSLY BY OPERATING BOTH SWITCHES AT THE SAME TIME.

 **WARNING** ALWAYS BEWARE OF OVERHEAD POWER CABLES AND NEVER UNFOLD OR FOLD THE SPRAYER BOOMS WHEN PARKED BENEATH THESE CABLES.

- F. LEVEL THE BOOM PARALLEL TO THE GROUND, USING THE BOOM TILT SWITCH NUMBER 6.

G. LOWER THE BOOMS TO THE REQUIRED WORKING HEIGHT. (SEE JET CHART).


IF THE WORKING HEIGHT IS SUCH THAT THE BOOMS ARE AT THE BOTTOM OF THEIR TRAVEL IT IS REQUIRED TO RAISE THEM 50mm., SO THAT THE BOOM SUSPENSION HAS ROOM TO WORK.

H. FOLDING THE BOOMS IS THE REVERSE OF THE ABOVE PROCEDURE.

**NOTE:** MB-TRAC MOUNTED MACHINES.

ON THESE MACHINES IT IS NECESSARY TO PARTIALLY OPEN THE BOOMS IN ORDER TO GAIN ACCESS TO AND FROM THE CAB AS FOLLOWS:-

FOLD THE BOOMS IN THE USUAL WAY, BUT DO NOT LOWER FULLY INTO THE BOOM RESTS WHICH RUN ALONGSIDE THE SPRAY TANK. WHEN THE BOOMS ARE JUST CLEAR OF THE RESTS, UNFOLD THE BOOMS SLIGHTLY. THE RIGHT HAND BOOM WILL BE PREVENTED FROM OPENING BY THE BOOM STOP ON THAT SIDE OF THE MACHINE. THE LEFT HAND BOOM SHOULD BE OPENED SUFFICIENTLY TO ALLOW THE CAB DOOR TO OPEN, BUT THE BOOM MUST STILL BE ABLE TO REST ON THE REAR BOOM SUPPORT TO ALLOW THE BOOMS WEIGHT TO BE CARRIED ON THE RESTS.


 **CAUTION.** NEVER TRAVEL WITH THE BOOMS IN A PARTIALLY FOLDED POSITION, ALWAYS ENSURE THAT THE BOOMS ARE PARKED SECURELY IN THE RESTS.

#### OPERATION OF TILT FOR BOOM INCLINATION.

THE BOOM ON THE CLEANACRES AIRTEC SPRAYER, PIVOTS ON A SINGLE, CENTRAL BEARING. THE BOOM IS PROVIDED WITH A FLOAT FACILITY BY MEANS OF SPRINGS AND SHOCK ABSORBERS. UNDER NORMAL CONDITIONS THESE WILL ACCOUNT FOR UNDULATIONS IN TERRAIN. IF HOWEVER, THE FIELD IS DRILLED ALONG THE SIDE OF A BANK, IT MAY BE NECESSARY TO INCLINE THE BOOM TO THE LEFT OR RIGHT TO FOLLOW THE CONTOUR OF THE GROUND.

TO INCLINE THE BOOM TO THE LEFT, THE BOOM TILT SWITCH (NO. 6) SHOULD BE MOVED TO THE LEFT AND VICE-VERSA FOR THE RIGHT.

WHEN RETURNING TO LEVEL GROUND, RETURN THE BOOM TO THE FLOAT POSITION.

 **IMPORTANT:** ALWAYS ENSURE THAT THE BOOMS ARE LEVEL BEFORE FOLDING. IF THIS IS NOT DONE, DAMAGE TO THE BOOMS MAY RESULT.

## GENERAL GUIDELINES FOR THE SELECTION OF SPRAY QUALITY

**⚠ CAUTION:** THE FOLLOWING GUIDELINES ARE DESIGNED TO HELP OPERATORS SELECT AIRTEC SETTINGS. HOWEVER, REFERENCE SHOULD BE MADE TO YOUR AGRONOMIST FOR GUIDANCE ON TANK MIX COMPATIBILITY, SPRAY QUALITY SELECTION AND VOLUME REQUIREMENTS.

### SOIL APPLIED HERBICIDES

FOR OVERALL APPLICATION TO BARE SOIL, THE TARGET IS CLEAR AND THE SPRAY QUALITY SETTING IS NOT HIGHLY CRITICAL, PROVIDED THE CHEMICAL IS DEPOSITED ON THE GROUND EVENLY WITHOUT TOO MUCH GAP BETWEEN SPRAY DROPS, AT THE REQUIRED DOSE, AND WITH MINIMUM DRIFT.

### FOLIAR APPLIED PRODUCTS

APPLICATIONS TO PLANT FOLIAGE ARE MORE COMPLEX. THE TARGET FOR FOLIAGE HERBICIDES IS THE WEED AND NOT THE CROP, WHEREAS FUNGICIDES, INSECTICIDES, AND CROP GROWTH REGULATORS ARE AIMED AT THE CROP. IN MANY INSTANCES A TANK MIX OF THE ABOVE PRODUCTS REQUIRES AN APPLICATION SYSTEM TO COMPROMISE BETWEEN THE REQUIREMENTS FOR DIFFERENT DROPLET SIZES.

WITH CONVENTIONAL SPRAYERS, HERBICIDES, SYSTEMIC FUNGICIDES, INSECTICIDES, AND GROWTH REGULATORS ARE GENERALLY APPLIED AT A PRESSURE OF 3 BARS (45 PSI) THROUGH FAN NOZZLES, AT VOLUMES OF 100-200 L/ha (10-20 G.P.A.).

AT THESE PRESSURES AND VOLUMES, THERE IS A TENDENCY TOWARDS PRODUCING A WIDE RANGE OF DROP SIZES FROM 1 - 600µm IN DIAMETER WITHIN WHICH ARE A VERY LARGE NUMBER OF SMALL DROPS OF LESS THAN 100µm WHICH ARE LIABLE TO DRIFT OVER LONG DISTANCES. ALTHOUGH THE TOTAL AMOUNT OF ACTIVE INGREDIENT FALLING OUTSIDE THE TARGET AREA MAY BE VERY SMALL, THE ENVIRONMENTAL EFFECTS

COULD BE UNDESIRABLE. THE VERY LARGE DROP FRACTION (350um upwards) IS ALSO UNDESIREABLE DUE TO RUN OFF FROM FOLIAGE LEADING TO A RELATIVELY SMALL PROPORTION OF THE SPRAY DROPS BEING RETAINED BY THE FOLIAGE. MANUFACTURERS APPLICATION RATES TEND TO ALLOW FOR A RELATIVELY HIGH PROPORTION OF WASTE TO COPE WITH THE INEFFICIENCY OF THE HYDRAULIC NOZZLE.

AIRTEC SPRAYERS EMIT A SIGNIFICANTLY SMALLER FRACTION OF LARGE DROPLETS, AND THOSE WHICH IT DOES ARE AIR INCLUDED AND CONSEQUENTLY RETAIN ON THE TARGET, WHICH LEADS TO LESS WASTAGE AND A COMMENSURATE REDUCTION OF THE AMOUNT OF WATER REQUIRED TO TREAT A UNIT AREA. IN ADDITION THE FINE DROPLETS (1 - 100 um) ARE ENTRAINED IN THE CURTAIN OF AIR EMITTED FROM THE NOZZLE AND ARE CONSEQUENTLY CARRIED INTO THE CROP CANOPY RATHER THAN DRIFTING OUTSIDE THE TARGET AREA.

ALL THE REQUIRED SPRAY QUALITY CATEGORIES CAN BE ACHIEVED WITH THE AIRTEC, NOT BY CHANGING NOZZLES AS WITH CONVENTIONAL SPRAYERS, BUT MERELY BY ALTERING THE COMBINATION OF AIR AND WATER PRESSURES. ONE CAN ALSO CHANGE SPRAY QUALITY CATEGORY IN THE MIDDLE OF AN APPLICATION WITHOUT ALTERING THE APPLICATION RATE - PARTICULARLY USEFUL IF SPRAYING IS NOT TO BE INTERRUPTED DUE AN INCREASE IN WIND SPEED.



## SPRAY QUALITY GUIDE.

---

IF A CHEMICAL IS APPLIED AT THE CORRECT APPLICATION RATE, AT THE CORRECT TIME, AND WITH THE CORRECT SPRAY QUALITY FOR THE TARGET, YOU WILL GET THE BEST POSSIBLE RESULTS FROM YOUR CHEMICALS WITH MINIMUM RISK OF DRIFT.

THE BRITISH CROP PROTECTION COUNCIL HAS DIVIDED SPRAY QUALITIES INTO FIVE CATEGORIES. VERY FINE, FINE, MEDIUM, COARSE, VERY COARSE. THE VERY FINE AND VERY COARSE CATEGORIES ARE NOT COMMONLY USED.

YOUR CHEMICAL LABEL RECOMMENDATIONS MAY WELL REFER TO A PREFERRED SPRAY QUALITY TO GIVE BEST EFFECTIVENESS AND SAFETY, SO YOU SHOULD SELECT A SETTING TO GIVE THIS QUALITY. IF NO SPRAY QUALITY IS RECOMMENDED BY THE CHEMICAL MANUFACTURER, USE A MEDIUM SPRAY QUALITY. THE SPRAY QUALITY FOR EACH SETTING IS INDICATED IN THE JET CHART (APPENDIX 1), AND WITH THE AIRTEC YOU SHOULD HAVE NO PROBLEM IN SELECTING A SUITABLE SETTING.

---

| SPRAY QUALITY | USED FOR  | LEAF RETENTION | DRIFT RISK  |
|---------------|---|----------------|---|
| <hr/>         |   |                |   |
| FINE          | GOOD COVER, e.g. SOME FUNGICIDES AND INSECTICIDES | GOOD           | MEDIUM/HIGH. WARNING: DO NOT USE FOR VERY TOXIC PRODUCTS OR WHERE DRIFT MAY CAUSE PROBLEMS. |
| <hr/>         |   |                |   |
| MEDIUM        | MOST PRODUCTS. GENERAL HERBICIDES                 | GOOD           | MEDIUM  |
| <hr/>         |   |                |   |
| COARSE        | SOIL-APPLIED HERBICIDES                           | POOR           | LOW   |

---

## CALIBRATION PROCEDURE.

-----

ONCE YOU HAVE SELECTED AND FITTED THE CORRECT NOZZLE AND DECIDED ON THE AIRTEC SETTING, IT IS THEN NECESSARY TO CALIBRATE YOUR SPRAYER.

1. READ LABEL ON THE CHEMICAL PACK (OR ACCOMPANYING LEAFLET) FOR RECOMMENDED SPRAY QUALITY, AND APPLICATION RATE. THE LABEL WILL ALSO ADVISE YOU ON THE SAFETY EQUIPMENT THAT YOU ARE OBLIGED TO WEAR.
2. CARRY OUT A TRIAL RUN TO ESTABLISH A FORWARD SPEED WHICH GIVES AN ACCEPTABLE LEVEL OF BOOM STABILITY AND A GEAR WHICH GIVES A PTO SPEED OF 540 RPM.
3. CARRY OUT SPEED CHECK OVER 100 METRES, USING GEAR AND P.T.O. RPM AS ABOVE. TAKE THE TIME IN SECONDS, TO COVER THE DISTANCE.

ESTABLISH THE FORWARD SPEED FROM THE FORMULA:

$$360 \div \text{TIME (IN SECONDS)} = \text{SPEED (IN KILOMETERS PER HOUR)}$$

4. SELECT REQUIRED AIRTEC SETTING BY REFERRING TO THE JET CHART FOR THE RESTRICTORS FITTED (APPENDIX 1). ESTABLISH THE DESIRED AIR AND LIQUID PRESSURE TO GIVE THE CORRECT APPLICATION RATE AT THE DESIRED FORWARD SPEED AND SPRAY QUALITY.

MAKE A NOTE OF THE REQUIRED PRESSURES AND NOZZLE OUTPUT. ALSO NOTE THE OTHER SETTINGS THAT GIVE DIFFERENT SPRAY QUALITIES WITHIN THE SAME APPLICATION RATE SHOULD YOU NEED TO ALTER THE SETTINGS TO ALLOW FOR A CHANGE IN THE WEATHER CONDITIONS.

5. TURN BOOM SECTIONS ON AND SET PRESSURES.

6. CHECK NOZZLE SPRAY PATTERNS AND ALIGNMENT VISUALLY.  
REPLACE ANY ROGUE NOZZLES.

7. RE-CHECK PRESSURES

8. COMPARE THE OUTPUT OF INDIVIDUAL NOZZLES BY USE OF THE CALIBRATION BEAKER PROVIDED. CHECK AT LEAST ONE NOZZLE ON EACH BOOM SECTION AND COMPARE THE OUTPUT OVER ONE MINUTE. RE-ADJUST LIQUID PRESSURE IF NECESSARY TO ACHIEVE DESIRED OUTPUT. NOTE: LIQUID PRESSURE WILL ONLY NEED ALTERING BY A SMALL AMOUNT TO ACHIEVE A RELATIVELY LARGE DIFFERENCE IN FLOW.

9. IF THE OUTPUT DIFFERS BY A LARGE AMOUNT, RE-CHECK CALIBRATION AND CALCULATIONS AND CHANGE SETTINGS IF NECESSARY.

10. SET BOOM HEIGHT.

THE MINIMUM NOZZLE HEIGHT ABOVE TARGET IS 50cm.

#### MISCELLANEOUS CONVERSION FACTORS

ONE GALLON PER ACRE = 11.23 LITRES PER HECTARE.

ONE MILE = 5,280 FEET = 1610 METRES = 1.61 KILOMETRES.

ONE GALLON = 4.55 LITRES.

ONE POUND PER SQUARE INCH (PSI) = 0.070 BARS = 6.895 KILOPASCAL.

ONE BAR = 14.5 PSI.

## FILTRATION SYSTEM.

### PRESSURE FILTRATION

CLEANACRES SPRAYERS ARE ALL FITTED WITH A MAIN IN-LINE SELF-FLUSHING PRESSURE FILTER. THE FILTER IS MOUNTED JUST BEFORE THE PRESSURE MANIFOLD. THE SELF-FLUSHING FILTER OBVIATES THE NEED TO REMOVE THE FILTER ELEMENT FOR DAILY CLEANING.

FILTERING MODE: VALVE CLOSED. DIRT IS DEPOSITED INSIDE THE SCREEN.


FLUSHING MODE: VALVE OPEN. FLUSH DIRT THROUGH OPEN VALVE.

### SUCTION FILTRATION

FILTRATION ON THE SUCTION SIDE OF THE SPRAYER IS PROVIDED BY THE MEANS OF A FILTER THAT ENSURES ALL LIQUID IS FILTERED WHEN SPRAYING OR FILLING. THE FILTER IS LOCATED BETWEEN THE SUCTION VALVE AND THE PUMP.

WASH OUT THE FILTER BY UNSCREWING, (WHEN TANK IS EMPTY), THE FILTER BOWL AND REMOVING THE FILTER ELEMENT. WHEN RE-ASSEMBLING SMEAR WATER PUMP GREASE ON THE SEAL TO PREVENT PINCHING AND LEAKS.

AS WITH THE PRESSURE FILTER THERE ARE A RANGE OF COLOUR CODED ELEMENTS: 20 MESH, COARSE (BLACK). 30 MESH, COARSE (WHITE) AND 50 MESH, MEDIUM (BLUE). THE 30 MESH FILTER IS FITTED AS STANDARD.

 **CAUTION:** WHEN RE-ASSEMBLING FILTERS IT IS IMPORTANT NOT TO OVERTIGHTEN AS THIS WILL CRUSH THE 'O'RINGS AND CAUSE LEAKING OR AIR TO BE DRAWN INTO THE SYSTEM. AIR LEAKING THROUGH THE SUCTION FILTER IS A COMMON FAULT WHICH CAN STOP THE SPRAYER FUNCTIONING CORRECTLY.

USE OF CONSTANT RECIRCULATING SYSTEM. (CRS).

THE LIQUID LINES ON THE BOOM ARE FITTED WITH A CONSTANT RECIRCULATING SYSTEM. THIS ENSURES THAT WHEN LOW VOLUMES ARE BEING USED, POWDERED FORMULATION WILL NOT START TO SETTLE OUT IN THE LINE.

THE SPRAYLINE IS FED FROM THE END NEAREST TO THE SPRAYTANK. AT THE OTHER END OF THE SPRAYLINE THERE IS A RETURN PIPE ROUTED BACK DOWN THE BOOM AND BACK TO THE TANK. INSIDE THE TANK THERE ARE DROP PIPES WHICH RETURN THE EXCESS LIQUID NOT SPRAYED THROUGH THE LINE.

## **FLUSHING SPRAYER THROUGH WITH FRESH WATER**

### **WHEN SPRAY TANK IS EMPTY.**

THE SPRAYER SHOULD ALWAYS BE FLUSHED THROUGH EVERY DAY BEFORE A CHANGE OF CHEMICALS. THIS IS CRITICAL TO AVOID DAMAGE TO RUBBER COMPONENTS SUCH AS PUMP DIAPHRAGMS.

PLEASE CARRY OUT THE FOLLOWING PROCEDURE:

1. TURN OFF THE P.T.O.
2. TURN THE SUCTION VALVE (FIGURE 2) TO 'SELF FILL' AND CONNECT THE SELF FILL HOSE. PLACE THE FILTER END OF THE SELF FILL HOSE IN A CLEAN WATER SOURCE.
3. SET THE PRESSURE VALVE TO 'SPRAY' (FIGURE 2) AND ENGAGE THE P.T.O. WITH ALL OF THE BOOM SECTIONS IN THE "ON" POSITION. FLUSH WATER THROUGH THE BOOM FOR APPROXIMATELY FIVE MINUTES.
4. TURN OFF THE P.T.O. AND TURN THE C.R.S. TAPS TO DUMP. THEN REPEAT THE PROCESS AS IN 3 AND WHILST CARRYING THIS OUT TURN ON THE FLUSHING FILTER, THE COMPRESSOR, AND PRESSURE GAUGE DRAIN VALVES INDIVIDUALLY FOR 10 SECONDS EACH.
5. IF IT IS LIKELY TO FREEZE EITHER ADD ANTIFREEZE THROUGH THE CHEMICAL INDUCTION BOWL, OR PARK THE SPRAYER IN A SUITABLY INSULATED BARN (SEE FROST PROTECTION PAGE 37).

6. THOROUGHLY WASH DOWN THE EXTERIOR OF THE SPRAYER, USING A SUITABLE DETERGENT.

7. OPEN ALL DRAIN TAPS AS LISTED BELOW:-

COMPRESSOR


TANK

SIGHT GAUGE

FLUSHING FILTER

PRESSURE GAUGE.

8. CLEAN THE SUCTION FILTER AND REPLACE.


 CAUTION. ENSURE THAT WASHING OUT OF THE SPRAYER IS CARRIED OUT WHERE SPRAY RESIDUE WILL CAUSE NO HARM TO LIVESTOCK OR THE ENVIRONMENT IN ACCORDANCE WITH THE GUIDELINES SET OUT IN THE FOOD AND ENVIRONMENT PROTECTION ACT, 1985.

## FLUSHING OUT THE SPRAYLINES AND PLUMBING

### WHEN CHEMICAL IN TANK.

AS DAILY FLUSHING OUT IS CRITICAL, IT MAY BE NECESSARY TO FLUSH OUT THE BOOMS AND PLUMBING WITH FRESH WATER, WHILST THERE IS STILL CHEMICAL IN THE SPRAY TANK.


PARK THE SPRAYER ON FIRM, LEVEL GROUND, WITH THE BOOMS UNFOLDED. SET THE PRESSURE VALVE TO 'SPRAY', CONNECT A FRESH WATER SUPPLY TO THE 'SELF FILL'. DISCONNECT THE LIQUID PRESSURE REGULATING PIPE FROM THE TOP OF THE TANK AND ALLOW WATER FROM THIS PIPE TO FLOW ONTO THE GROUND. TURN THE COMPRESSOR RETURN TAP TO THE DRAIN POSITION SO THAT WATER FROM THE COMPRESSOR AGAIN DRAINS ONTO THE GROUND. TURN THE CRS RETURN TAPS TO DRAIN AND TURN ON ALL OF THE BOOM SECTIONS.

 **CAUTION** NEVER SHUT OFF A BOOM SECTION WHEN FLUSHING SPRAYER THROUGH AS ABOVE.

ENGAGE THE P.T.O. AND ALLOW FRESH WATER TO PASS THROUGH THE SPRAY LINES, FOR ABOUT 5 MINUTES, TO ENSURE THAT ALL CHEMICAL IS THOROUGHLY RINSED OUT.

OPEN THE FOLLOWING DRAIN TAPS: COMPRESSOR, FLUSHING FILTER, AND PRESSURE GAUGE.

THE CHEMICAL IN THE TANK WILL NOT HAVE BEEN DILUTED AND CAN BE LEFT OVERNIGHT.

 **IMPORTANT:** IF CHEMICAL HAS BEEN LEFT IN THE TANK OVERNIGHT OR FOR A SIMILAR TIME PERIOD, THEN ALWAYS ALLOW A PERIOD OF AGITATION BEFORE SPRAYING. OBSERVE CHEMICAL MANUFACTURERS STORAGE RECOMMENDATIONS AS SOME PRODUCTS GO SOLID IF LEFT STANDING.






Your Cleanacres Sprayer may be fitted with a CL 90 Air Cooled, Oil Lubricated Compressor. It is very important that you use the correct oil. Using the incorrect oil may cause the compressor to over heat and partially seize.

The following compressors may be fitted:

|                             |                                   |
|-----------------------------|-----------------------------------|
| MDC 72 or 124 Liquid Cooled | : Shell Corena H150 or equivalent |
| CL 90 Air Cooled            | : 15/40 Turbo Diesel Engine Oil   |
| KP 85A Kompressor           | : Shell Talpa or equivalent       |
| Hammond E 150 or E 50       | : No oil lubrication              |

If you are unsure please do not hesitate to contact us.

# AR150bp



## Hosetail Options AR150


|                              |          |
|------------------------------|----------|
| 30mm x 90° Hosetail (Liner)  | 47580040 |
| 1 1/4" BSP (F) Cap           | 47580060 |
| 1 1/4" BSP Nipple            | 47580030 |
| 50mm 90° Hosetail (Liner)    | 47760020 |
| + 2" BSP (F) Cap             | 47760040 |
| + 1 1/4" x 2" BSP Nipple     | 47760030 |
| 35mm x 90° Hosetail (Liner)  | 47392130 |
| + 1 1/2" BSP (F) Cap         | 47540540 |
| + 1 1/4" x 1 1/2" BSP Nipple | 47540530 |

★ = Items in Winter Overhaul Kit - 47KIT150

| Ref. | Description            | Qty | Part No. |
|------|------------------------|-----|----------|
| B 1  | 50mm 90° Hosetail      | 1   | 47760020 |
| 2    | Hosetail Nut           | 1   | 47760040 |
| 3    | 'O' Ring               | 1   | 47620210 |
| 4    | Hexagon Nipple         | 1   | 47760030 |
| 5    | 'O' Ring               | 2   | 47250310 |
| 6    | Inlet Manifold         | 1   | 47760220 |
| 7    | Nut 8MA                | 16  | 47380240 |
| 8    | Cylinder Head          | 4   | 47750100 |
| ★ 9  | 'O' Ring               | 8   | 47680070 |
| ★ 10 | Valve                  | 8   | 47759050 |
| 11   | Bolt 12MA x 70         | 4   | 47750070 |
| 12   | 3/8" BSP Plug          | 1   | 47030171 |
| 13   | Piston Sleeve          | 4   | 47750110 |
| 14   | Bolt 12MA x 65         | 12  | 47750060 |
| 15   | Screw                  | 2   | 47680350 |
| 16   | 'O' Ring               | 1   | 47580230 |
| 17   | Oil Reservoir Cap      | 1   | 47750050 |
| 18   | Oil Reservoir          | 1   | 47750030 |
| 19   | Gasket                 | 1   | 47750040 |
| 20   | Body                   | 1   | 47760010 |
| 21   | Body Gasket            | 1   | 47680250 |
| 22   | Body Plate             | 1   | 47680020 |
| 23   | Bolt 10MA x 25         | 6   | 47160670 |
| 24   | Hexagon Nipple         | 1   | 47540530 |
| 25   | 'O' Ring               | 1   | 47250310 |
| 26   | Hosetail Nut           | 1   | 47540540 |
| 27   | 35mm 90° Hosetail      | 1   | 47392130 |
| 28   | Diaph. Retaining Nut   | 4   | 47550131 |
| 29   | Diaph. Retaining Plate | 4   | 47580090 |
| ★ 30 | Diaphragm              | 4   | 47550085 |
| 31   | Stud                   | 4   | 47550270 |

| Ref. | Description           | Qty | Part No. |
|------|-----------------------|-----|----------|
| 32   | Piston Ring           | 4   | 47500260 |
| 33   | Piston                | 4   | 47750120 |
| 34   | Outlet Manifold       | 1   | 47760070 |
| 35   | Piston Spindle 48 x 8 | 4   | 47160700 |
| 36   | Circlip 18mm          | 8   | 47160691 |
| 37   | Con Rod (price each)  | 1   | 47760140 |
| 38   | Needle Bearing        | 2   | 47750090 |
| 39   | Spacer Ring           | 2   | 47750130 |
| 40   | Spacer                | 2   | 47540040 |
| 41   | Bearing               | 2   | 47230350 |
| 42   | Seal                  | 2   | 47230380 |
| 43   | Circlip 62mm          | 2   | 47200390 |
| 44   | Pump Base             | 2   | 47760200 |
| 45   | Shaft                 | 1   | 47750170 |
| 47   | Washer                | 2   | 47380241 |
| 48   | Washer                | 4   | 47250141 |
| 49   | Washer                | 16  | 47390311 |
| 50   | Bung                  | 2   | 47330170 |
| 59   | P.T.O. Guard          | 1   | 47540660 |
| 60   | Screw 8M8 x 15        | 3   | 47180431 |

|     |                   |   |          |
|-----|-------------------|---|----------|
| A 5 | 'O' Ring          | 1 | 47390290 |
| 7   | Nut 8MA           | 2 | 47380240 |
| 51  | Stud 8MA x 40     | 2 | 47390670 |
| 52  | Diaphragm         | 1 | 47550190 |
| 53  | 'O' Ring          | 1 | 47650542 |
| 54  | Air Valve         | 1 | 47180020 |
| 55  | Upper Air Chamber | 1 | 47620230 |
| 56  | Screw 8MA x 45    | 8 | 47380250 |
| 57  | Nut 8MA           | 8 | 47390270 |
| 58  | Lower Air Chamber | 1 | 47680180 |
| 59  | Air Receiver Assy | 1 | 37ARARA1 |

**Hosetail Options AR230/260**

|                              |          |
|------------------------------|----------|
| 35mm x 90° Hosetail (Liner)  | 47392130 |
| + 1 1/4" BSP (F) Cap         | 47540540 |
| + 1 1/4" x 1 1/2" BSP Nipple | 47540530 |
| 50mm x 90° Hosetail (Liner)  | 47760020 |
| + 2" BSP (F) Cap             | 47760040 |
| + 1 1/4" x 2" BSP Nipple     | 47760030 |
| or 1 3/4" x 2" BSP Nipple    |          |
| (for Inlet only)             | 47750330 |
| 30mm x 90° Hosetail (Liner)  | 47580040 |
| + 1 1/4" BSP (F) Cap         | 47580060 |
| + 1 1/4" BSP Nipple          | 47580030 |

★ = Items in Winter Overhaul Kit

| Ref. Description           | Qty | Part No. |
|----------------------------|-----|----------|
| 1 50mm Hosetail            | 1   | 47750160 |
| 1 60mm Hosetail            | 1   | 47750150 |
| 2 'O' Ring                 | 1   | 47030281 |
| 3 Bolt 12MA x 70           | 4   | 47750070 |
| 4 Pump Base                | 1   | 47750200 |
| 5 'O' Ring                 | 1   | 47620210 |
| 6 Inlet Manifold           | 1   | 47750220 |
| 7 Nut 8MA                  | 24  | 47380240 |
| 8 Cylinder Head            | 6   | 47750100 |
| ★ 9 'O' Ring               | 12  | 47680070 |
| ★ 10 Valve                 | 12  | 47759050 |
| 11 Circlip 62mm            | 2   | 47200390 |
| 12 Shaft (AR230BP)         | 1   | 47750170 |
| 12 Shaft (AR260BP)         | 1   | 47750171 |
| 13 Piston Sleeve (AR230BP) | 6   | 47750111 |
| 13 Piston Sleeve (AR260BP) | 6   | 47750112 |
| 14 Bolt 12MA x 65          | 20  | 47750060 |
| 15 Bolt 8MA x 35           | 2   | 47680350 |
| 16 'O' Ring                | 1   | 47580230 |
| 17 Cap (AR180)             | 1   | 47750051 |
| 17 Oil Reservoir Cap       | 1   | 47750050 |
| 18 Oil Reservoir           | 1   | 47750030 |
| 19 Gasket                  | 1   | 47750040 |
| 20 Body                    | 1   | 47750010 |
| 21 Body Gasket             | 1   | 47680250 |
| 22 Body Plate              | 1   | 47680020 |
| 23 Bolt 10MA x 25          | 6   | 47160670 |
| 24 Hexagon Nipple          | 1   | 47540530 |
| 25 'O' Ring                | 1   | 47250310 |
| 26 Hosetail Nut            | 1   | 47540540 |
| 27 35mm 90° Hosetail       | 1   | 47392130 |
| 28 Diaph. Retaining Nut    | 6   | 47550131 |
| 29 Diaph. Retaining Plate  | 6   | 47580090 |
| ★ 30 Diaphragm             | 6   | 47550085 |
| 31 Stud                    | 6   | 47550270 |
| 32 Piston Ring             | 6   | 47500260 |

| Ref. Description          | Qty | Part No. |
|---------------------------|-----|----------|
| 33 Piston                 | 6   | 47750120 |
| 34 Outlet Manifold        | 1   | 47750420 |
| 35 Piston Spindle 48 x 18 | 6   | 47160700 |
| 36 Circlip 18mm           | 12  | 47160691 |
| 37 Con Rod                | 6   | 47750140 |
| 38 Needle Bearing         | 2   | 47750090 |
| 39 Spacer Ring            | 2   | 47750130 |
| 40 Spacer                 | 2   | 47540040 |
| 41 Bearing                | 2   | 47230350 |
| 42 Seal                   | 2   | 47230380 |
| 43 Nut 8MA                | 2   | 47380241 |
| 45 Washer                 | 4   | 47250141 |
| 46 Washer                 | 24  | 47390311 |
| 47 Screw                  | 3   | 47180430 |
| 48 PTO Guard              | 1   | 47540660 |
| 50 Oil Outlet             | 1   | 47750230 |
| 51 Bung                   | 1   | 47030171 |
| 52 Screw                  | 2   | 47540290 |
| 53 Hosetail               | 1   | 47760020 |
| 54 Hosetail Nut           | 1   | 47760040 |
| 55 Nipple                 | 1   | 47750330 |
| 56 'O' Ring               | 1   | 47030281 |
| 57 Upper Air Chamber      | 1   | 47620230 |
| 58 Diaphragm              | 1   | 47550190 |
| 59 Lower Air Chamber      | 1   | 47680180 |
| 60 Screw Bolt 8MA 45      | 8   | 47380250 |
| 61 Nut 8MA H65            | 8   | 47390270 |
| 62 Stud                   | 2   | 47390670 |
| 63 'O' Ring               | 1   | 47390290 |
| 64 Elbow                  | 1   | 47760300 |
| 65 Bung                   | 2   | 47330170 |
| 66 Nut                    | 1   | 47760310 |
| 67 'O' Ring               | 1   | 47650540 |
| 68 Air Valve              | 1   | 47180020 |
| 69 Air Receiver Assy      | 1   | 37ARARA1 |

# CLEANACRES MACHINERY SERVICE BULLETIN.

---

6TH JUNE 1990

NO: 101

REF: NEOPRENE BLOCKS FITTED TO E.C.A. SPRAYERS

These are located at the centre of the back frame and cushion the yaw on the booms.

The blocks will wear, and therefore should be inspected on a weekly basis. If they show signs of wear, or damage, they should be replaced immediately. The blocks are available from your local dealer or Cleanacres Machinery.

When fitting new blocks, they should not be greased as this will cause them to distort and will seriously reduce their service life.

Expensive damage can occur to the fold rams and the centre section if the sprayer is used with worn or damaged neoprene blocks. Whilst checking blocks, ensure that all nuts and bolts in the block housing assembly are tight, and that the ram ends are properly secured.

Damage to the sprayer resulting from worn blocks will not be covered under warranty.

Alistair Hett  
Service Manager

# PRE AND POST SPRAYING CHECKS

| PERIOD        | ITEM/AREA                 | CHECK   |
|---------------|---------------------------|---|
| DAILY         | LIQUID SUCTION FILTER     | Clean And Replace.  |
| PRE-SPRAYING: | COMPRESSOR AIR FILTER     | Check not clogged with dust, replace if necessary.  |
| ⚠ WARNING:    |                           | ⚠ CAUTION: When conditions are dusty it can become clogged and damage to the compressor could result.                       |
| dis-engage    |                           |   |
| P.T.O. and    |                           |   |
| switch off    |                           |   |
| tractor       |                           |   |
| engine.       |                           |   |
|               | COMPRESSOR OIL RESERVOIR. | Check level. Only use specified oil. examine pipe to compressor for air locks or damage. Check for any water contamination. |
|               | PUMP OIL                  | Check level. only use specified oil.  |
|               | P.T.O. SHAFT              | Grease universal joints and guard.  |
|               | TANK/PLUMBING             | Ensure that absolutely no resedue has been left over from the last spray application.                                       |
| DAILY         | COMPRESSOR                | Check the required  |
| PRE-SPRAYING: |                           | No. of oil drops  |
| CHECKS WITH   |                           | per minute.   |
| Sprayer       |                           | ⚠ CAUTION: Switch   |
| running with: |                           | off immediately if  |
| water in      |                           | not obtained.   |
| tank..        |                           | Check water is  |
|               |                           | circulating in  |
|               |                           | compressor by   |
|               |                           | opening compressor  |
|               |                           | drain tap.  |
|               | PUMP                      | Check oil is not overflowing from cap.  |
|               |                           | ⚠ CAUTION: switch   |
|               |                           | off immediately if  |
|               |                           | this is occuring.   |

## LIQUID FERTILIZER.

ALL CLEANACRES AIRTEC SPRAYERS ARE SUITABLE FOR APPLYING LIQUID FERTILIZER SOLUTION IF A SECOND FERTILIZER LINE IS FITTED. THE AIRTEC NOZZLE IS NOT SUITABLE FOR THE APPLICATION OF LIQUID FERTILIZER. IT IS IMPORTANT TO REALIZE THAT FERTILIZER SOLUTION IN THIS CASE IS CONSIDERED ONLY AS NITROGEN, AS EITHER A COMPOUND OR STRAIGHT, IN A FULLY AQUEOUS SOLUTION. FERTILIZER OF THE SUSPENSION TYPE CANNOT BE APPLIED USING STANDARD CLEANACRES SPRAYERS.

TO AVOID PLANT SCORCH, THE USE OF DRIBBLE BARS IS RECOMMENDED AS THESE PRODUCE VERY LARGE DROPLETS WHICH ROLL OFF THE PLANT LEAVES.

### CHANGING TO SECOND SPRAYLINE.



1. ENSURE THAT THE SPRAYER HAS BEEN THOROUGHLY FLUSHED OUT.
2. AT THE TANK END OF EACH SPRAYLINE WILL BE FOUND MALE CAMLOCK FITTINGS. DISCONNECT THE LIQUID FEED LINE FROM THE AIRTEC SPRAY LINE AND CONNECT THE FEED LINE TO THE LIQUID FERTILIZER LINE.
3. FIT BLANKING CAPS TO THE AIRTEC SPRAYLINE TO PREVENT ACCESS BY FOREIGN MATTER.
4. THE SECOND LINE IS NOT FITTED WITH CRS AS IT IS USED FOR HIGH VOLUME SPRAYING SUCH AS LIQUID FERTILIZER. THE SPRAYER IS NOW READY TO SPRAY THROUGH THE SECOND LINE.

NOTE: THE AIR SYSTEM WILL HAVE NO EFFECT ON THE SECOND LINE AND THE SPRAYER WILL BE OPERATING AS A CONVENTIONAL SPRAYER. FOR CALIBRATION REFER TO THE LIQUID FERTILIZER CALIBRATION CHART.

|               |                     |                        |   |
|---------------|---------------------|------------------------|---|
| : PERIOD      | : ITEM/AREA         | : CHECK                | : |
| :             | :                   | :                      | : |
| DAILY         | C.R.S.              | : Check restrictors    | : |
| PRE-SPRAYING: |                     | : for blockages.       | : |
| CHECKS        |                     |                        | : |
| CONTINUED.    | AGITATION           | : visually check for   | : |
| :             | :                   | : flow.                | : |
| :             | BOOM SOLENOIDS      | : Check for operation: | : |
| :             | NOZZLES             | : Check for alignment: | : |
| :             | :                   | : & pattern, and that: | : |
| :             | :                   | : nozzle is correct    | : |
| :             | :                   | : for desired          | : |
| :             | :                   | : application rate.    | : |
| :             | GENERAL             | : Walk around machine: | : |
| :             | :                   | : to observe any       | : |
| :             | :                   | : leaks or chafing     | : |
| :             | :                   | : hoses.               | : |
| :             | COMPRESSOR PRESSURE | : Should be blowing    | : |
| :             | RELIEF VALVE        | : off when solenoids   | : |
| :             | :                   | : are switched off.    | : |
| :             | PRESSURE ADJUSTMENT | : Check full range of: | : |
| :             | :                   | : both liquid and air: | : |
| :             | :                   | : pressures is         | : |
| :             | :                   | : available.           | : |
| :             | BOOM HEIGHT         | : Adjust to 50cm       | : |
| :             | :                   | : above desired        | : |
| :             | :                   | : target or top of     | : |
| :             | :                   | : crop whichever is    | : |
| :             | :                   | : taller, if using     | : |
| :             | :                   | : skids adjust to      | : |
| :             | :                   | : suit.                | : |
| :             | CALIBRATE           | : Always carry this    | : |
| :             | :                   | : out using clean      | : |
| :             | :                   | : water.               | : |

YOU ARE NOW READY TO ADD THE CHEMICAL.

|          |                   |                       |   |
|----------|-------------------|-----------------------|---|
| : PERIOD | : ITEM / AREA     | : CHECK               | : |
| :        | :                 | :                     | : |
| DURING   | PRESSURE SETTINGS | : Ensure they remain  | : |
| SPRAYING | :                 | : correct & constant. | : |
| :        | :                 | : Re-adjust if        | : |
| :        | :                 | : necessary.          | : |

| PERIOD             | ITEM/AREA                          | <div style="text-align: center;">  CAUTION: </div> CHECK  |
|--------------------|------------------------------------|---|
|                    |                                    | Flickering of the<br>liquid pressure<br>guage will indicate<br>a pump problem or<br>an empty tank. Stop<br>immediately.   |
| DURING<br>SPRAYING | NOZZLE BLOCKAGES                   | Be aware that a<br>nozzle may only<br>partially block<br>showing a smoky<br>stream of droplets.   |
|                    | FORWARD SPEED & P.T.O.<br>R.P.M.   | Keep both as<br>constant as<br>possible.  |
|                    | PRESSURES                          | Keep a constant<br>watch for any<br>changes in either<br>liquid or air<br>pressures and re-<br>adjust as necessary.   |
|                    | BOOM SHUT OFF<br>RESPONDING SLOWLY | Will be due either<br>to faulty solenoid<br>or more likely the<br>C.R.S. restrictor<br>being blocked.   |
|                    | HEIGHT/ANGLE OF BOOM               | Boom must be<br>parallel to ground<br>and at correct<br>height. Use boom<br>controls to adjust.   |
|                    | TANK CONTENTS                      | Do not start<br>another pass if you<br>do not have enough<br>in the tank to<br>complete that pass.  |
|                    | WEATHER CONDITIONS                 | If wind increases<br>and yet there is an<br>overriding urgency<br>to finish the job,<br>select a coarser<br>droplet pressure<br>setting for the<br>same application<br>rate.<br><div style="text-align: center;">  CAUTION: Consult<br/> your agronomist if<br/> in doubt about<br/> spray quality range: </div> |




| PERIOD   | ITEM/AREA                        | CHECK   |
|--|----------------------------------|---|
| AFTER<br>SPRAYING  | SURPLUS CHEMICAL IN<br>THE TANK. | Either pump into a<br>storage tank or if<br>small amount<br>dispose of safely<br>in accordance with<br>Codes of Practice.                           |
|  | FLUSHING OUT                     | Flush out and wash<br>down. <b>CAUTION:</b> if<br>flushing out is not<br>done on a daily<br>basis, damage may<br>occur to the pump<br>and plumbing. |
|  | FROST PROTECTION                 | Anti-freeze or<br>store in a frost<br>free building.  |
| WEEKLY or<br>or more fre-<br>quently if<br>large acreage<br>being covered: | BOOM BREAKBACK                   | Check full<br>breakback is<br>unrestricted.   |
|  | ALL GREASE POINTS                | Grease.   |
|  | GEARBOX OIL                      | Check level.  |
| MONTHLY  | NOZZLE WEAR                      | Calibrate and check:<br>flood tips for wear:<br>Also check visual<br>pattern and<br>alignment.  |
|  | ELECTRICAL<br>CONNECTIONS        | Clean and spray<br>with a water<br>dispersing oil.  |
|  | PLUMBING                         | Check for any signs:<br>of hoses chafing.   |
|  | AIR CONNECTIONS                  | Check for leaks and:<br>spray with water<br>dispersing oil.   |
| SEASONALLY   | FLOOD TIPS                       | Remove and<br>thoroughly clean.   |
|  | COMPRESSOR                       | Flush out oil<br>reservoir and<br>replace oil.  |
|  | GEARBOX                          | Change oil.   |

## ROUTINE MAINTENANCE

GUIDELINES FOR REPLACEMENT COMPONENTS ARE AS FOLLOWS:-

| <u>COMPONENT</u>                 | <u>PERIOD</u>   |
|----------------------------------|---|
| COMPRESSOR AIR FILTER            | : CHECK FREQUENTLY PARTICULARLY IN<br>: DUSTY CONDITIONS - REPLACE MONTHLY  |
| PUMP DIAPHRAGMS                  | :   |
| D.C.V. RUBBERS                   | : ANNUALLY OR EVERY 5,000 HECTARES  |
| C.R.S. RETURNS RESTRICTORS       | : WHICHEVER IS SOONER.  |
| PRESSURE SET DIAPHRAGM & GASKETS | :   |
| POLO MINT WASHERS                | :   |
| FILTER O-RINGS                   | :   |
| SOLENOID DIAGHRAMS               | : BI-ANNUALLY OR EVERY 10,000<br>: HECTARES, WHICHEVER IS   |
| PUMP VALVES                      | : SOONER.   |
| FLOODTIPS                        | : WHEN THEY SHOW SIGNS OF WEAR. THIS<br>: IS CAUSED BY POOR QUALITY WATER OR<br>: THE ABRASIVENESS OF THE CHEMICALS.<br>: A SIMPLE CHECK IS TO RUB THE END<br>: OF A MATCH STICK ALONG THE FLOOD<br>: TIP FACE AND IF YOU FEEL A DIMPLE<br>: THEY NEED REPLACING. |
| RESTRICTORS                      | : WHEN THE FLOW RATE VARIES BY MORE<br>: THAN 5% FROM CHART.  |

 CAUTION: COMPONENTS, PARTICULARLY THOSE MADE OF RUBBER, WILL LAST LONGER IF THE SPRAYER IS FLUSHED OUT AFTER USE EVERY DAY.

## BOOM MAINTENANCE AND SETTING.

THE CLEANACRES BOOM REQUIRES VERY LITTLE ADJUSTMENT. THE FOLLOWING INSTRUCTIONS WILL GIVE MANY YEARS OF TROUBLE FREE SERVICE.

1. GREASE ALL NIPPLES ON THE BOOMS ONCE EVERY WEEK.
2. BEFORE DELIVERY THE BOOM TILT IS SET SO THAT THE BOOMS ARE LEVEL WHEN THE TILT RAM IS IN ITS HALF WAY POSITION AS THE LIFE OF THE MACHINE PROGRESSES IT MAY BE NECESSARY TO ADJUST THE TENSION ON THE BALANCING SPRINGS IN ORDER TO KEEP THE BOOMS LEVEL.

THIS OPERATION SHOULD ONLY BE CARRIED OUT WITH THE SPRAYER STANDING ON LEVEL GROUND WITH THE BOOMS FULLY UNFOLDED. SET THE TILT RAM TO ITS HALF WAY POSITION AND THEN ADJUST THE SPRING TENSIONING BOLTS TO SET THE BOOM LEVEL. ALWAYS TIGHTEN THE LOCK NUTS AFTER ADJUSTING THE SPRING TENSION.

3. THE CLEANACRES BOOMS ARE FITTED WITH A BREAKBACK SECTION AT THE END OF EACH BOOM. THESE SECTIONS SHOULD ALWAYS BE FREE TO MOVE, AND THE SPRING TENSION SHOULD BE SUCH THAT THE BREAKBACK SECTION RETURNS FIRMLY BACK TO ITS REST POSITION AFTER BREAKBACK, BUT IS STILL FREE TO BREAKBACK.

NOTE: THE BREAKBACK SYSTEM IS DESIGNED TO PREVENT DAMAGE TO THE BOOM IN THE EVENT OF ACCIDENTALLY CATCHING THE BOOM IN A HEDGE OR ON OTHER OBJECTS. IT IS NOT DESIGNED TO BE PURPOSEFULLY DRIVEN INTO TREES OR TELEGRAPH POLES WHILST SPRAYING.

### FROST PROTECTION PRECAUTION

FROST DAMAGE TO SPRAYERS CAN BE VERY COSTLY AND TIME CONSUMING.  
IF THE FOLLOWING POINTS ARE OBSERVED THEN DAMAGE WILL BE PREVENTED.

1. DRAIN TANK.
2. OPEN ALL SPRAYLINE CONTROL VALVES AND SOLENOIDS, TURN THE CRS  
TAPS TO DRAIN AND DISCONNECT THE SPRAYLINE FEEDS.
3. REMOVE SUCTION FILTER BOWL AND OPEN VALVE ON PRESSURE FILTER.
4. DISCONNECT PUMP FEED AND SUCTION LINES AND DRAIN.
5. DRAIN COMPRESSOR.
6. DRAIN SIGHT GUAGE.

#### IMPORTANT

7. ALWAYS FLUSH THROUGH WITH ANTIFREEZE OR STORE IN FROST FREE  
BARN.

## FAULT FINDING

### WHILST FILLING.

| Fault  | Possible Cause                                  | Remedial Action  |
|--|---|--|
| Water not self filling or filling slowly.            | Lift from water source too long.<br>(over 3.7m) | Reduce lift.   |
|  | Chemical Induction Bowl valve left open.        | Close valve.   |
|  | Pressure valve not set to self fill.            | Set to self fill.  |
|  | Blocked filter on self-fill hose.               | Clean.   |
|  | Blocked suction filter.                         | Clean.   |
|  | Air leak on self fill hose.                     | Tighten connections<br>check camlock seals.<br>repair hole in pipe<br>or replace pipe. |
|  | Suction filter drawing in air.                  | Tighten, Check seals   |
|  | Faulty or worn pump.                            | Replace diaphragms<br>and/or valve.  |
|  | Air lock in pump.                               | Prime pump.  |
| Chemical incorporator not working or working slowly. | Suction valve fully open.                       | Partially close valve.<br><b>⚠ CAUTION</b> Never fully close as pump may be damaged.   |

# FAULTS WHILE SPRAYING

| Faults    | Possible Cause                           | Remedial Action  |
|-----------|--|--|
| No spray  |  |  |
| Pressure. | Electrics not connected.                 | Connect up and switch on.  |
|           | No water in tank.                        | Check sight guage and fill if necessary.                                     |
|           | Pressure valve set to Self fill.         | Set to spray.  |
|           | Chemical induction bowl valve left open. | Close valve.   |
|           | Blocked suction filter.                  | Clean.   |
|           | Air leak around suction filter           | Check filter bowl is seating correctly on sealing ring.                      |
|           | Air leak at suction valve.               | Tighten. Check seals.  |
|           | Air leak on suction pipe.                | Check joints for leaks and tighten if necessary.                             |
|           | Blocked pressure filter.                 | Check and clean. Change to coarser mesh if frequent blockages.               |
|           | Faulty or worn pump.                     | Replace diaphragms and/or valves.  |
|           | Blocked breather hole in tank lid.       | Clear obstruction.   |
|           | Blockage in suction pipe.                | If machine will self fill with water, blockage is in suction pipe from tank. |

| Fault                                | Possible Cause  | Remedial Action  |
|--------------------------------------|---|--|
| Cannot attain required nozzle output | Worn or wrong jets.<br>Application rate or pressure excessive for pump.     | Fit new or correct jets.<br>Contact dealer.                  |
| Spray pressure not constant.         | Faulty diaphragm in pump.<br>(diaphragm pumps only)                         | Replace diaphragm.   |
| spray pressure too high.             | Faulty pressure regulation valve.   | Contact Dealer.  |
| Sudden Pressure Loss.                | No liquid in tank.<br>Liquid pipe burst.<br>Blocked breather hole in tank.  | Check Sight Gauge.<br>Check for leaks.<br>Clear Obstruction. |
| Cannot Stop Spraying.                | Electrical fault on master ON/OFF:<br>spray switch or valves                | Stop PTO, Effect<br>repair if possible.                      |
| Nozzle Drip When Spray Switched Off. | Worn or faulty diaphragm check<br>valves on nozzle body.                    | Replace.   |
| Spray Pattern Incorrect.             | Incorrect boom height for jets<br>selected.<br>Spray fans not offset by 5°. | Check height.<br>Adjust nozzles.                             |

| Fault                           | Possible Cause   | Remedial Action   |
|---------------------------------|--|---|
| Frequent<br>Blocked Jets.       | Damaged or incorrectly fitted<br>pressure filter.                          | Replace.  |
|                                 | Machine not flushed out after use.   | Flush system<br>thoroughly using<br>approved detergent. |
|                                 | Pressure filter too coarse   | Select finer pressure<br>filter mesh                    |
|                                 | Chemical damage to rubber hose   | Complete overhaul<br>required - contact<br>Dealer.      |
| Frequent<br>Blocked<br>Filters. | Dirty water.<br><br>If pressure filter then suction<br>filter inoperative. | Find different<br>water source.<br>Check and replace.   |
|                                 | Filter mesh too fine.  | Fit coarser mesh.                                       |

#### FAULTS ON ELECTRICS

|                                   |   |   |
|-----------------------------------|---|---|
| No Electric<br>Control at<br>all. | Electrics not connected.                                  | Connect up.                                   |
|                                   | Blown line fuse.  | Check and replace.                            |
|                                   | Sprayer plugged into trailer<br>lights socket on tractor. | Connect up with spray<br>control unit socket. |



# FAULTS ON BOOM OPERATION

| Fault                          | : Possible Cause  | : Remedial Action.   |
|--------------------------------|---|--|
| Booms will not raise.          | : Hydraulic pipe not connected.   | : Connect with tipping pipe outlet.                                      |
|                                | : Restrictor valve on hydraulic pipes not open.                                   | : Adjust.  |
|                                | : Hydraulic connections not fully inserted.                                       | : Check and fully tighten.   |
| Boom will not open.            | : Booms on rests.   | : Lift clear.  |
|                                | : Hydraulic feed pipe trapped.  | : Check.   |
| Booms open too quickly.        | : Restrictors not set correctly.  | : Adjust.  |
|                                | : Tractor hydraulics excessive for sprayer system without adaptor, e.g. Ford 7600 | : Reduce engine speed or contact dealer for diverter valve to be fitted. |
|                                |   |  |
| Booms will Not Close.          | : Hydraulic pipe trapped.   | : Check.   |
|                                | : Restrictor on hydraulics closed.  | : Check and open.  |
|                                | : Booms not raised sufficiently.  | : Raise to maximum height.   |
| Boom will not maintain height. | : Hydraulic leak.   | : Check unions and tighten if necessary.                                 |
|                                | : Spool valve faulty.   | : Contact dealer.  |

| Fault                       | Possible Cause.                 | Remedial Action                      |
|-----------------------------|---------------------------------|--------------------------------------|
|                             | Damaged accumulator.            | Contact dealer.                      |
|                             | Leaking tractorhydraulics.      | Fit pilot operated<br>check valve.   |
|                             | Worn or damaged centre springs. | Adjust spring tension<br>or replace. |
|                             | Pivot springs too slack.        | Tighten.                             |
| Too much boom:<br>movement. | Worn or damaged pivot.          | Replace.                             |
| Boom sag.                   | Badly adjusted stay bars.       | Adjust.                              |

#### FAULT ON DRAINING

|                          |                                    |                               |
|--------------------------|------------------------------------|-------------------------------|
| Tank will not:<br>drain. | Blocked breather hole in tank lid: | Remove lid and clear<br>hole. |
|                          | Blocked sump drain.                | Check and clear.              |

#### FAULTS ON AIR SYSTEM.

|                                 |  |   |
|---------------------------------|--|---|
| Cannot obtain:<br>air pressure. | Air filter blocked.                              | Change filter.  |
|                                 | Air pressure guage disconnected.                 | Reconnect pipe.   |
|                                 | PTO not at 540.                                  | Set PTO speed.  |
|                                 | Pressure relief valve not screwed:<br>in enough. | Screw down valve.<br>and adjust to blow<br>off at 28 psi. |

| Fault                    | Possible Cause.                                   | Remedial Action                            |
|--------------------------|---|--|
|                          | Air solenoids not opening or faulty.              | Check electrical connections & solenoids.  |
|                          | Coupling damaged between gear box and compressor. | Fit new coupling.                          |
|                          | Compressor damaged.                               | Contact Dealer.                            |
|                          | No liquid in tank.                                | Fill tank.                                 |
|                          | Pressure guage faulty.                            | Change guage.                              |
|                          | Electrics not connected.                          |  |
| Compressor over heating. | Liquid pipes from and to Compressor blocked.      | Unblock feed & return lines.               |
|                          | Compressor not flushed out properly.              | Flush through with clean water.            |
|                          | P.T.O. Speed too fast.                            | Adjust to 540 r.p.m.                       |
|                          | Filter blocked.                                   | Replace.                                   |
| Air pressure too high.   | P.T.O. running too fast.                          | Adjust to 540 r.p.m.                       |
|                          | Relief valve too tight.                           | Adjust relief valve to blow off at 28 psi. |
|                          | Faulty butterfly valve.                           | Replace valve.                             |

////////////////////// LEGAL REQUIREMENTS ////////////////////////

HEALTH AND SAFETY AT WORK ACT 1974 IMPOSES GENERAL DUTIES ON EMPLOYERS TO ENSURE, SO FAR AS IS REASONABLY PRACTICABLE, THE SAFETY AND ABSENCE OF RISKS TO HEALTH IN THE USE, HANDLING, STORAGE AND TRANSPORT OF SUBSTANCES SUCH AS PESTICIDES.

ALSO THE SELF EMPLOYED AND EMPLOYEES MUST TAKE REASONABLE CARE FOR THE HEALTH AND SAFETY OF THEMSELVES AND EMPLOYEES MUST CO-OPERATE WITH OTHERS CONCERNING ANY DUTY OR REQUIREMENT.

THE POISONOUS SUBSTANCES IN AGRICULTURE REGULATIONS 1984 REQUIRE AN EMPLOYER TO PROVIDE EMPLOYEES WITH PRESCRIBED PROTECTIVE CLOTHING AND NOT TO ALLOW THEM TO PERFORM A SCHEDULED OPERATION UNLESS IT IS WORN.

ALSO EMPLOYERS MUST PROVIDE ACCOMMODATION FOR PROTECTIVE CLOTHING AND EMPLOYEES PERSONAL CLOTHING TOGETHER WITH SUITABLE WATER FOR DRINKING, PERSONAL WASHING, AND WASHING PROTECTIVE CLOTHING PLUS FACILITIES FOR CLEANING SPRAYER EQUIPMENT. SIMILARLY, SELF EMPLOYED PERSONS MUST PROVIDE THEMSELVES WITH PROTECTIVE CLOTHING AND ACCOMMODATION FOR IT. ALL OPERATORS MUST WEAR THE APPROPRIATE PROTECTIVE CLOTHING FOR THE WORK BEING DONE.

REGULATIONS MADE UNDER THE FOOD AND ENVIRONMENT PROTECTION ACT 1985 MUST ALSO BE COMPLIED WITH.

IT IS MOST IMPORTANT THAT THE CORRECT PROTECTIVE CLOTHING IS WORN AT ALL TIMES WHEN HANDLING PESTICIDE. CLEANACRES MACHINERY STOCK A FULL RANGE OF PROTECTIVE CLOTHING, IF YOU THINK YOU ARE NOT PROPERLY EQUIPPED IN THIS RESPECT PLEASE CONTACT US FOR ADVICE.

SERVICE INSTRUCTIONS FOR MODEL MDC 72 AND 124  
ROTARY WATERCOOLED COMPRESSOR.

CHECKS BEFORE USE

BEFORE RUNNING THE FIRST TIME AFTER INSTALLATION OR MAINTENANCE MAKE THE FOLLOWING CHECKS:-

FILL OIL BOTTLE WITH SHELL CORENA H 150 OIL OR EQUIVALENT.

WHEN STARTING UP CHECK DAILY THE TWO OIL DRIP INDICATORS MOUNTED ON THE PUMP END OF THE COMPRESSOR.

THE MINIMUM FLOW RATES FOR EACH INDICATOR ARE:-

MDC 72 .....4 DROPS PER MINUTE

MDC124 .....6 DROPS PER MINUTE

IF ADJUSTMENT OF THE OIL PUMP IS NECESSARY REFER TO INSTRUCTION SHEET IC067.

OPERATING INSTRUCTIONS

REGULARLY INSPECT FILTER FITTED TO THE INTAKE PIPELINE. FAILURE TO CARRY OUT THIS MAINTENANCE WILL RESULT IN LOSS OF PERFORMANCE AND OVERHEATING.

CHECK THE BLADES FOR WEAR EVERY 2000 RUNNING HOURS AND RENEW IF THE RUBBING TIPS HAVE WORN REDUCING THE DEPTH TO  $1 \frac{5}{16}$ " - REFER TO CLEANACRES MACHINERY TO HAVE THIS CHECK CARRIED OUT.

! CAUTION: THE COMPRESSOR DEPENDS UPON THE SPRAY LIQUID FOR COOLING THE CYLINDER AND MUST NOT BE RUN WITHOUT LIQUID IN THE SPRAY TANK, OTHERWISE THE COMPRESSOR WILL OVERHEAT AND SEIZURE WILL OCCUR.

IT IS ESSENTIAL THAT THE WATER JACKET IS DRAINED OF ALL LIQUID DURING FROSTY WEATHER.

THE FOLLOWING INSPECTIONS MUST BE CARRIED OUT BY A CLEANACRES MACHINERY APPOINTED ENGINEER.

#### TO INSPECT AND CHANGE SLIDING BLADES

REMOVE OIL PIPES FROM DRIVE END. UNDO 3 SCREWS (27) AND TAKE OFF END CAP (3) AND OUTER BEARING SHIM (19). REMOVE LOCK NUT (16) AND TAP WASHER (17). UNDO 6 NUTS (25) AND LIGHTLY TAP OFF COVERPLATE (2) COMPLETE WITH OUTER RACE OF ROLLER BEARING (13) AND BEARING SHIMS (19). AT THIS STAGE MEASURE AND NOTE THE THICKNESS OF THE SPECIAL GASKET (22) FITTED BETWEEN THE COVERPLATE AND CYLINDER.

THE BLADES CAN NOW BE INSPECTED. WHEN RENEWING THE SLIDING BLADES MAKE SURE THAT THEY SLIDE FREELY IN THEIR SLOTS AND IF NECESSARY REMOVE ANY HIGH SPOTS WITH EMERY CLOTH. THE TWO GROOVES IN ONE SIDE OF THE BLADES MUST BE IN THE LEADING FACE WHEN POSITIONED IN THE ROTOR SLOT.

#### TO CHANGE BEARINGS AND SHAFT SEALS

PROCEED AS ABOVE FOR CHANGING BLADES. THE SHAFT SEALS (15) CAN BE REMOVED FROM THE END CAP (3) AND INSPECTED. THE OUTER RACE OF THE ROLLER BEARING (13) MAY BE TAPPED FROM THE COVERPLATE, THIS RELEASES THE INNER BEARING SHIM (19). TO REMOVE THE INNER RACE FROM THE SHAFT, FIRST REMOVE THE SPACING RING (7) BY CAREFULLY CRACKING IN HALF WITH A SHARP CHISEL. THIS WILL NOW PERMIT THE INNER RACE TO BE PULLED OFF THE SHAFT USING A TWO-LEG PULLEY DRAWER. BEFORE FITTING THE REPLACEMENT SPACING RING, FIRST ACCURATELY MEASURE THE WIDTH OF THE OLD RING AND GRIND THE REPLACEMENT TO THE SAME WIDTH TO GIVE CORRECT CLEARANCES ON ASSEMBLY.

TO DISMANTLE THE REAR END, FIRST REMOVE OIL PIPES AND BRACKET WITH OIL DRIP INDICATORS, AND TAKE OFF OIL PUMP (21) AND SLIP OUT THE COUPLING (8). UNDO THREE SCREWS (28) AND TAKE OFF END CAP (4) AND OUTER BEARING SHIM (19). UNDO 6 NUTS (25) AND REMOVE THE REAR COVERPLATE (2) COMPLETE WITH ROTOR AND SHAFT ASSEMBLY (5) FROM THE CYLINDER (1). AGAIN NOTE THE THICKNESS OF THE GASKET FITTED AT THIS END. HOLD THIS ASSEMBLY FIRMLY IN A VICE, GRIPPING ON THE ROTOR DIAMETER WITH PROTECTION ON THE VICE JAWS.

TAKE OFF CIRCLIP (18) TAKING CARE NOT TO DAMAGE OR LOSE ANY SHIM THAT MAY BE FITTED BETWEEN THE CIRCLIP AND BEARING, AND USING A PULLEY DRAWER PULL THE COVERPLATE (2) AND BALL BEARING (14) FROM THE SHAFT. THIS RELEASES THE INNER BEARING SHIM (19). THE BALL BEARING (14) CAN BE TAPPED OUT FROM THE COVERPLATE. REFER TO INSTRUCTION SHEET IC 067 FOR MAINTENANCE OF THE BEKA LUBRICATION PUMP.

#### TO RE-ASSEMBLE

IT IS ESSENTIAL THAT ALL PARTS ARE PERFECTLY CLEAN BEFORE RE-ASSEMBLY. WHEN REPLACING THE OIL SEALS (15) ENSURE THAT THE TENSION SPRING SIDE FACES THE BEARING FOR BOTH SEALS.

LIGHTLY SMEAR THE SHAFT WITH GREASE TO ASSIST ASSEMBLY. RE-BUILD WITH GASKETS HAVING EXACTLY THE SAME THICKNESS AS THE ORIGINALS.

THE CORRECT ASSEMBLY CLEARANCES ARE:-

- A) BETWEEN COVERPLATE AND ROTOR - REAR END .003/.004"
- B) BETWEEN COVERPLATE AND ROTOR - DRIVE END MDC 72 .013/.015"  
MDC124 .020/.022"
- C) BETWEEN ROTOR AND CYLINDER BORE .005/.006"

FAILURE TO FOLLOW THE ABOVE INSTRUCTIONS CAN CAUSE LOSS OF PERFORMANCE OR SEIZURE.

WHEN ORDERING SPARE PARTS ALWAYS QUOTE THE MACHINE CHASSIS NO.

## MAINTENANCE OF COMPRESSOR OIL RESERVOIR.

REFILL THE OIL TANK REGULARLY TO ENSURE THAT THE LEVEL IS NOT ALLOWED TO FALL TO THE POINT WHERE AIR CAN BE DRAWN INTO THE OIL PUMP. USE ONLY CLEAN NEW OIL OF THE GRADE RECOMMENDED IN THE INSTRUCTIONS FOR THE MACHINE.

AT LEAST EVERY YEAR, OR IF THE MACHINE HAS BEEN OUT OF USE FOR A LONG PERIOD, OR IF THE OIL BOTTLE HAS BECOME CONTAMINATED, THE PUMP MUST BE THOROUGHLY FLUSHED WITH PARAFFIN TO CLEAR ANY OIL RESIDUES WHICH MAY HAVE SOLIDIFIED IN THE CONTROL DUCTS. TO CARRY OUT THIS OPERATION WE RECOMMEND THE FOLLOWING PROCEDURE.

- 1) STOP MACHINE AND DISCONNECT OIL FEED PIPE FROM TANK.
- 2) REMOVE OIL TANK FROM CRADEL, DRAIN OIL, WASH OUT WITH PARAFFIN AGAIN ENSURING THAT ALL RESIDUES ARE REMOVED, AND REPLACE. RECONNECT FEED PIPE TO PUMP.
- 3) FILL TANK WITH SUFFICIENT PETROL/KEROSINE TO COVER OIL FILTER ELEMENT. LOOSEN FEED PIPE CONNECTION AT PUMP END UNTIL ALL AIR HAS BEEN DISPELLED. RETIGHTEN PIPE CONNECTION.
- 4) START MACHINE UNDER NO LOAD CONDITIONS AND RUN UNTIL PARAFFIN BEGINS TO FLOW FROM OIL PUMP DISCHARGE POINTS. THIS OPERATION WILL TAKE APPROXIMATELY 15 MINUTES AND PROVIDING THAT THE MACHINE IS NOT ON LOAD NO DAMAGE WILL OCCUR.
- 5) STOP MACHINE, DRAIN OIL TANK AND FILL WITH RECOMMENDED GRADE OF OIL. ENSURE THAT OIL PUMP FEED PIPE IS PRIMED, AND THAT THERE ARE NO AIR LOCKS.




# AIRTEC 2. (PLASTIC NOZZLE) CALIBRATION CHART 35 RESTRICTOR

| Pressure Settings |      | Spray Quality | Flow Rate<br>Mls/Min<br>Per Nozzle | Application Rates   |    |      |      |                               |                       |      |     |     |      |
|-------------------|------|---------------|------------------------------------|---------------------|----|------|------|-------------------------------|-----------------------|------|-----|-----|------|
|                   |      |               |                                    | Ltrs per HA. at KPH |    |      |      | Flow Rate<br>F.ozs<br>Per Min | Galls per acre at MPH |      |     |     |      |
|                   |      |               |                                    | 8                   | 10 | 12   | 14   |                               | 4                     | 5    | 6   | 7   | 8    |
| 10                | 15   | Fine          | 332                                | 50                  | 40 | 33.2 | 28.5 | 11.6                          | 5.5                   | 4.4  | 3.7 | 3.1 | 2.75 |
| 15                | 20   | Very Fine     |                                    |                     |    |      |      |                               |                       |      |     |     |      |
| 20                | 25   | Very Fine     |                                    |                     |    |      |      |                               |                       |      |     |     |      |
| 10                | 17   | Medium        | 386                                | 58                  | 46 | 39   | 33   | 13.5                          | 6.4                   | 5.1  | 4.3 | 3.6 | 3.2  |
| 15                | 23   | Fine          |                                    |                     |    |      |      |                               |                       |      |     |     |      |
| 20                | 28   | Very Fine     |                                    |                     |    |      |      |                               |                       |      |     |     |      |
| 10                | 19   | Medium        | 420                                | 63                  | 50 | 42   | 36   | 14.7                          | 7.0                   | 5.6  | 4.6 | 4.0 | 3.5  |
| 15                | 24   | Medium        |                                    |                     |    |      |      |                               |                       |      |     |     |      |
| 20                | 29   | Fine          |                                    |                     |    |      |      |                               |                       |      |     |     |      |
| 10                | 22   | Medium        | 465                                | 70                  | 56 | 46.5 | 40   | 16.3                          | 7.7                   | 6.2  | 5.1 | 4.4 | 3.8  |
| 15                | 26   | Medium        |                                    |                     |    |      |      |                               |                       |      |     |     |      |
| 20                | 32   | Fine          |                                    |                     |    |      |      |                               |                       |      |     |     |      |
| 10                | 24   | Medium        | 500                                | 75                  | 60 | 50   | 43   | 17.5                          | 8.3                   | 6.6  | 5.5 | 4.7 | 4.1  |
| 15                | 28   | Medium        |                                    |                     |    |      |      |                               |                       |      |     |     |      |
| 20                | 34   | Fine          |                                    |                     |    |      |      |                               |                       |      |     |     |      |
| 10                | 25   | Medium        | 525                                | 79                  | 63 | 52.5 | 45   | 18.4                          | 8.7                   | 7.0  | 5.8 | 5.0 | 4.3  |
| 15                | 30   | Medium        |                                    |                     |    |      |      |                               |                       |      |     |     |      |
| 20                | 36   | Fine          |                                    |                     |    |      |      |                               |                       |      |     |     |      |
| 10                | 28   | Coarse        | 580                                | 87                  | 70 | 58   | 50   | 20.3                          | 9.6                   | 7.7  | 6.4 | 5.5 | 4.8  |
| 15                | 33   | Medium        |                                    |                     |    |      |      |                               |                       |      |     |     |      |
| 20                | 39   | Medium        |                                    |                     |    |      |      |                               |                       |      |     |     |      |
| 10                | 31   | Coarse        | 615                                | 92                  | 74 | 61.5 | 53   | 21.6                          | 10.2                  | 8.1  | 6.8 | 5.8 | 5.1  |
| 15                | 36   | Medium        |                                    |                     |    |      |      |                               |                       |      |     |     |      |
| 20                | 40   | Medium        |                                    |                     |    |      |      |                               |                       |      |     |     |      |
| 15                | 41   | Coarse        | 680                                | 102                 | 82 | 68   | 58.3 | 24.0                          | 11.3                  | 9.0  | 7.5 | 6.4 | 5.6  |
| 20                | 46   | Coarse        |                                    |                     |    |      |      |                               |                       |      |     |     |      |
| 25                | 51   | Medium        |                                    |                     |    |      |      |                               |                       |      |     |     |      |
| 15                | 47   | Coarse        | 740                                | 111                 | 89 | 74   | 63.5 | 26.0                          | 12.3                  | 9.8  | 8.2 | 7.0 | 6.1  |
| 20                | 51   | Coarse        |                                    |                     |    |      |      |                               |                       |      |     |     |      |
| 25                | 56   | Medium        |                                    |                     |    |      |      |                               |                       |      |     |     |      |
| 15                | 50   | Coarse        | 790                                | 119                 | 95 | 79   | 68   | 28.0                          | 13.1                  | 10.5 | 8.7 | 7.5 | 6.5  |
| 20                | 56.5 | Coarse        |                                    |                     |    |      |      |                               |                       |      |     |     |      |
| 25                | 60   | Medium        |                                    |                     |    |      |      |                               |                       |      |     |     |      |

AGH. JULY 1991

# CONTROL BOX




# CONTROL BOX.

| ITEM | QUANTITY | PART NUMBER | DESCRIPTION |
|------|----------|-------------|-------------|
| 1    | 1        | BCA110-01   | SWITCH      |
| 2    | 7        | BCA110-02   | LIGHT       |
| 3    | 5        | BCA110-03   | SWITCH      |
| 4    | 5        | BCA110-04   | SWITCH      |
| 5    | 1        | BCA110-05   | SWITCH      |
| 6    | 3        | BCA110-06   | FUSE        |
| 7    | 3        | BCA110-07   | FUSE HOLDER |
| 8    | 4        | BCA110-08   | PLUG/SOCKET |

# LIQUID LINE and FITTINGS

## (4 SECTION)



BODM

R.H. SIDE

CENTRE SECTIONS.


L.H. SIDE

# LIQUID LINE & FITTINGS (4 SECTION)


| ITEM | QUANTITY | PART NUMBER | DESCRIPTION                                  |
|------|----------|-------------|--|
| 1    | 6        | DEEL1234    | 1/2" 3/4" ELBOW                              |
| 2    | 4        | DEEL1214    | 1/2" 1/4" ELBOW                              |
| 3    | 6        | DPA1234     | 1/2" 3/4" HOSETAIL                           |
| 4    | 2        | ECA104-01   | BREAK BACK SPRAYLINE (SPECIFY BOOM WIDTH)    |
| 5    | 2        | ECA104-02   | OUTER SECTION SPRAYLINE (SPECIFY BOOM WIDTH) |
| 6    | 2        | ECA104-03   | INNER SECTION SPRAYLINE                      |
| 7    | 2        | ECA104-04   | CENTRE SECTION SPRAYLINE                     |
| 8    | 48       | ME11        | AIRTEC NOZZLE (SPECIFY BOOM WIDTH)           |
| 9    | 48       | ECA104-05   | BAND CLAMP/HOSETAIL                          |
| 10   | 48       | IU15AQ2706  | SEAL   |
| 11   | 48       | IU14-Q1819  | SEAL   |
| 12   | 48       | IU15AQ2707  | SCREW  |

# AIR LINE and FITTINGS


## (4 SECTION)




## INNER SECTION



## OUTER SECTION




## BREAK BACK SECTION



# AIR LINE & FITTINGS (4 SECTION)

| ITEM           | QUANTITY | PART NUMBER | DESCRIPTION                 |                      |
|----------------|----------|-------------|-----------------------------|----------------------|
| 1              | 2        | BCA105-01   | BREAK BACK AIRLINE          | (SPECIFY BOOM WIDTH) |
| 2              | 2        | BCA105-02   | OUTER SECTION AIRLINE       | (SPECIFY BOOM WIDTH) |
| 3              | 2        | BCA105-03   | INNER SECTION AIRLINE       |                      |
| 4              | 2        | BCA105-04   | CENTRE SECTION AIRLINE      |                      |
| 5              | 8        | DPA1034     | 1" $\frac{3}{4}$ " HOSETAIL |                      |
| 6              | 4        | DEPL1034    | 1" $\frac{3}{4}$ " ELBOW    |                      |
| 7              | 4        | DEPL1034    | END CAP                     |                      |
| 8              | 48       | BCA105-05   | BAND CLAMP/HOSETAIL         |                      |
| 9              | 48       | IU15AQ2706  | SEAL                        |                      |
| 10             | 48       | IU14Q1819   | SEAL                        |                      |
| 11             | 48       | IU15AQ2707  | SCREW                       |                      |
| PVC REPAIR KIT |          | BCA105-08   |                             |                      |

# SELF FILL






# SELF FIT.

| ITEM | QUANTITY | PART NUMBER | DESCRIPTION     |
|------|----------|-------------|-----------------|
| 1    | 1        | DEEL200     | 2" ELBOW        |
| 2    | 2        | IJ58000032  | BODY NUT        |
| 3    | 2        | IJ58000036  | SOCKET          |
| 4    | 2        | IJ58000064  | O-RING          |
| 5    | 1        | BCA109-01   | VALVE BODY      |
| 6    | 1        | TFM08-200   | 45 DEGREE ELBOW |
| 7    | 1        | DP9912-200F | CAMLOCK         |
| 8    | 1        | IJ56003005  | 2" 3 WAY VALVE  |


# DISTRIBUTION MANIFOLD



# DISTRIBUTION MANIFOLD

| ITEM | QUANTITY | PART NUMBER        | DESCRIPTION             |
|------|----------|--------------------|-------------------------|
| 1    | 1        | IU55BD0300         | 1/2" VALVE              |
| 2    | 1        | DEEL1212           | 1/2" ELBOW              |
| 3    | 1        | DEF1200            | 1/2" CAP                |
| 4    | 1        | CT23120            | 3/4" P.R. VALVE         |
| 5    | 1        | SP030              | MANIFOLD                |
| 6    | 1        | DEA114/DEA114112   | HOSETAIL (SPECIFY PUMP) |
| 7    | 2        | DEEL112/DEEL112114 | ELBOW (SPECIFY PUMP)    |
| 8    | 2        | IU58000031         | BODY NUT                |
| 9    | 2        | IU58000035         | SOCKET                  |
| 10   | 2        | IU58000062         | O-RING                  |
| 11   | 1        | ECA108-01          | VALVE BODY              |
| 12   | 1        | IU56003004         | 1 1/2" 3-WAY VALVE      |

# BOOM (Steel work) and FITTINGS




# 18, 20, 24 METRE FLIP OVER BOOM STEEL WORK

| ITEM | QUANTITY | PART NUMBER | DESCRIPTION                                      |
|------|----------|-------------|--|
|      | 1        | ECA103-01   | CENTRE FRAME WORK                                |
| 1    | 1        | ECA103-02   | INNER SECTION LEFT HAND                          |
| 2    | 1        | ECA103-03   | INNER SECTION RIGHT HAND                         |
| 3    | 1        | ECA103-04   | OUTER SECTION LEFT HAND (SPECIFY BOOM WIDTH)     |
| 4    | 1        | ECA103-05   | OUTER SECTION RIGHT HAND (SPECIFY BOOM WIDTH)    |
| 5    | 1        | ECA103-06   | BRAKBACK SECTION LEFT HAND (SPECIFY BOOM WIDTH)  |
| 6    | 1        | ECA103-07   | BRAKBACK SECTION RIGHT HAND (SPECIFY BOOM WIDTH) |
| 7    | 2        | ECA103-08   | BRAKBACK PIN                                     |
| 8    | 2        | ECA103-09   | FOLDING LINK - OUTER BOOM                        |
| 9    | 2        | ECA103-10   | HINGE PIN - FLIPOVER LINKS                       |
| 10   | 2        | ECA103-11   | FOLDING LINK - INNER BOOM                        |
| 11   | 2        | ECA103-12   | RAM  |
| 12   | 2        | ECA103-13   | RAM PIN  |
| 13   | 2        | ECA103-14   | TOP PIN-CENTRE TO INNER BOOM                     |
| 14   | 2        | ECA103-15   | ADJUSTABLE TOP LINK                              |
| 15   | 6        | ECA103-16   | 1.1/8" UNC NUTS + 1" DIA. FLAT WASHER            |
| 16   | 2        | ECA103-17   | BOTTOM PIN - CENTRE TO INNER BOOM                |
| 17   | 2        | ECA103-18   | PIN-FLIPOVER LINK TO INNER BOOM                  |
| 18   | 2        | ECA103-19   | HINGE PIN - INNER TO OUTER BOOM                  |

|    |    |           |
|----|----|-----------|
| 20 | 2  | ECA103-21 |
| 21 | 14 | ECA103-22 |
| 22 | 4  | ECA103-23 |
| 23 | 2  | ECA103-24 |

TINE SPRING  
 GREASE NIPPLE  
 M8 BOLT X 25 LONG + M8 NUT  
 RAM BOLT M20X100 + M20 NUT

# **BACK FRAME and CENTRE SECTION**





18, 20, 24 METRE FLIP OVER BOOM, BACK FRAME, AND CENTRE SECTION

| ITEM | QUANTITY | PART NUMBER | DESCRIPTION                    |
|------|----------|-------------|--------------------------------|
| 1    | 1        | BCA102-01   | BACKFRAME                      |
| 2    | 1        | BCA102-02   | CENTRE SECTION                 |
| 3    | 1        | BCA102-03   | M16 X 110 HEX HD BOLT          |
| 4    | AS REQ   | BCA102-04   | "R" PIN                        |
| 5    | 2        | BCA102-05   | 20 DIA. FLAT WASHER            |
| 6    | 1        | BCA102-06   | TILT RAM                       |
| 7    | 2        | BCA102-07   | SPRING TENSIONER               |
| 8    | 1        | BCA102-08   | SPRING ROCKING LEVER           |
| 9    | 2        | BCA102-09   | FLANGE BEARING UNIT 40 BORE    |
| 10   | 2        | BCA102-10   | M16 X 80 HEX HD BOLT           |
| 11   | 3        | BCA102-11   | M16 NYLOC NUT                  |
| 12   | 8        | BCA102-12   | 16 DIA. WASHER                 |
| 13   | 4        | BCA102-13   | SPRING                         |
| 14   | 2        | BCA102-14   | SPRING                         |
| 15   | 2        | BCA102-15   | SPRING ANCHOR PLATE            |
| 16   | 1        | BCA102-16   | CENTRE PIVOT COLLAR            |
| 17   | 1        | BCA102-17   | M10 X 90 HEX HD BOLT + M10 NUT |
| 18   | 2        | BCA102-18   | URETHANE BLOCK                 |
| 19   | 1        | BCA102-19   | ANTI-YAW RAM MOUNTING BRACKET  |



# **BACK FRAME and CENTRE SECTION**




# 18, 20, 24 METRE FLIP OVER BOOM, BACK FRAME, AND CENTRE SECTION

| ITEM | QUANTITY | PART NUMBER | DESCRIPTION                    |
|------|----------|-------------|--------------------------------|
| 1    | 1        | ECA102-01   | BACKFRAME                      |
| 2    | 1        | ECA102-02   | CENTRE SECTION                 |
| 3    | 1        | ECA102-03   | M16 X 110 HEX HD BOLT          |
| 4    | AS REQ   | ECA102-04   | "R" PIN                        |
| 5    | 2        | ECA102-05   | 20 DIA. FLAT WASHER            |
| 6    | 1        | ECA102-06   | TILT RAM                       |
| 7    | 2        | ECA102-07   | SPRING TENSIONER               |
| 8    | 1        | ECA102-08   | SPRING ROCKING LEVER           |
| 9    | 2        | ECA102-09   | FLANGE BEARING UNIT 40 BORE    |
| 10   | 2        | ECA102-10   | M16 X 80 HEX HD BOLT           |
| 11   | 3        | ECA102-11   | M16 NYLOC NUT                  |
| 12   | 8        | ECA102-12   | 16 DIA. WASHER                 |
| 13   | 4        | ECA102-13   | SPRING                         |
| 14   | 2        | ECA102-14   | SPRING                         |
| 15   | 2        | ECA102-15   | SPRING ANCHOR PLATE            |
| 16   | 1        | ECA102-16   | CENTRE PIVOT COLLAR            |
| 17   | 1        | ECA102-17   | M10 X 90 HEX HD BOLT + M10 NUT |
| 18   | 2        | ECA102-18   | URETHANE BLOCK                 |
| 19   | 1        | ECA102-19   | ANTI-YAW RAM MOUNTING BRACKET  |

|    |   |           |                            |
|----|---|-----------|----------------------------|
| 21 | 4 | ECA102-21 | M20 X 125 HEX HD BOLT      |
| 22 | 7 | ECA102-22 | M20 NYLOC NUT              |
| 23 | 2 | ECA102-23 | RAM FOLDING                |
| 24 | 2 | ECA102-24 | SHOCK ABSORBER             |
| 25 | 2 | ECA102-25 | CARRIER FOR SHOCK ABSORBER |
| 26 | 2 | ECA102-26 | M20 X 125 HEX HD BOLT      |


**BACKFRAME and  
PANTOGRAPH ARM**




# BACKFRAME AND PANTOGRAPH ARM

| ITEM | QUANTITY | PART NUMBER | DESCRIPTION                                 |
|------|----------|-------------|---|
| 1    | 1        | ECA101-01   | BACK FRAME                                  |
| 2    | 1        | ECA101-02   | PANTOGRAPH ARMS LOWER                       |
| 3    | 2        | ECA101-03   | RAM   |
| 4    | 8        | ECA101-04   | PANTOGRAPH TABBED BOLTS M20 X 120 + M20 NUT |
| 5    | 1        | ECA101-05   | PANTOGRAPH ARMS UPPER                       |
| 6    | 2        | ECA101-06   | M16 X 100 + M20 NUT + WASHER                |
| 7    | 2        | ECA101-07   | M16 X 110 + M20 NUT + WASHER                |

# LIQUID MANIFOLD



## AIR BAND CLAMP



# AIRTEC NOZZLE PLASTIC

1 NAP 1

2 NAP 03

3 NAT 0002T

4 NAP 0235

5 NAP 05

6 NAT 0006

7 NAT Q1821

8 NAP 04

9 N214 Q1819


10 BCC 2

11 N2066356

12 N215 AQ2701

13 N215 AQ2706

14 N215 AQ2704






# LIQUID MANIFOLD

| ITEM | QUANTITY | PART NUMBER        | DESCRIPTION         |                |
|------|----------|--------------------|---------------------|----------------|
| 1    | 1        | ECAS107-01         | MANIFOLD            |                |
| 2    | 1        | DPFL112/DPFL112114 | ELBOW               | (SPECIFY PUMP) |
| 3    | 1        | CT344-1-2          | 1" 2-WAY VALVE      |                |
| 4    | 4        | CT23520            | 1/2" THROTTLE VALVE |                |
| 5    | 4        | DPFL1234           | 1/2" 3/4" ELBOW     |                |
| 6    | 4        | DPFL3434           | 3/4" ELBOW          |                |

# INCORPORATOR CONTROL ASSEMBLY



## INCORPORATOR CONTROL ASSEMBLY

| ITEM | QUANTITY | PART NUMBER | DESCRIPTION   |
|------|----------|-------------|---------------|
| 1    | 1        | DEPL114     | 1" ELBOW      |
| 2    | 2        | IJ58000030  | 1" BODY NUT   |
| 3    | 2        | IJ58000034  | 1" SOCKET     |
| 4    | 2        | IJ58000060  | 1" O-RING     |
| 5    | 1        | ECA106-01   | 1" VALVE BODY |
| 6    | 1        | ECA106-102  | REDUCING BUSH |
| 7    | 1        | DPTT200     | 2" TEE        |
| 8    | 1        | DPA200      | 2" HOSE/TAIL  |
| 9    | 1        | DEM200      | 2" SOCKET     |
| 10   | 1        | IJ56100303  | 1" VALVE      |

## USEFUL CONTACTS

|              |       |        |               |
|--------------|-------|--------|---------------|
| MARK CURTOYS | SALES | OFFICE | (0451) 60721  |
|              |       | CAR    | 0860 414039   |
|              |       | HOME   | (0285) 651644 |


\*\*\*\*\*

|                 |           |                 |
|-----------------|-----------|-----------------|
| CLIVE CHRISTIAN | TECHNICAL | (090 855) 222   |
|                 |           | CAR 0860 638942 |

\*\*\*\*\*

|               |         |        |              |
|---------------|---------|--------|--------------|
| ALISTAIR HETT | SERVICE | OFFICE | (0451) 60721 |
|               |         | CAR    | 0860 637495  |
|               |         | HOME   | (0451) 30117 |


# FLUSHING FILTER



FLUSHING FILTER

| REF.NO. | PART NO. | DESCRIPTION  |
|---------|----------|--------------|
| 1       | 0082     | FILTER BODY  |
| 2       | 0083     | O RING       |
| 3       | 0084     | FILTER GAUZE |
| 4       | 0085     | HOUSING      |
| 5       | 0086     | NIPPLE       |
| 6       | 0087     | TAP          |

SELF FILL ASSEMBLY



# SELF FILL ASSEMBLY

| REF.NO. | PART NO. | DESCRIPTION   |
|---------|----------|---------------|
| 1       | 0087     | TAP           |
| 2       | 0088     | TEE ASSY.     |
| 3       | 0089     | 3 WAY TAP     |
| 4       | 0090     | O RING        |
| 5       | 0091     | CAMLOCK ASSY. |
| 6       | 0092     | ELBOW ASSY.   |
| 7       | 0093     | FILTER BODY   |
| 8       | 0094     | O RING        |
| 9       | 0095     | FILTER GAUZE  |
| 10      | 0096     | HOUSING       |
| 11      | 0097     | RING          |



**SERVICE INSTRUCTIONS FOR MODEL CL 90  
ROTARY BLOWERS AND VACUUM PUMPS**

**INSTALLATION**

The machine should be sited in a cool, clean, well ventilated position. If these conditions are not available the intake must be piped from a more suitable location. Ample room should be left for inspection.

If the machine is not required for immediate use the inlet and outlet must be kept covered otherwise entry of foreign matter through the ports could cause serious damage.

On vacuum pumps the connecting pipework on the intake side must be thoroughly cleaned to remove internal rust and scale. Use PTFE tape for making joints since surplus from jointing compounds will damage the blades if drawn into the machine. This also applies to the outlet joint, and pipework on the inlet of blowers.

**CHECKS BEFORE USE**

Before running the machine for the first time after installation or maintenance, make the following checks :-

Fill the lubricator with **SHELL RIMULA X 15W/40 OR EQUIVALENT**

Check that the machine is free by turning the shaft through a few revolutions.

Check that the direction of rotation is anti-clockwise when viewed from the drive shaft.

The pump speed must not normally exceed 1800 rpm.

**OPERATING INSTRUCTIONS**

Regularly inspect any filters fitted to the pipeline. Failure to carry out this maintenance will result in loss of performance and overheating.

Check blades for wear every 5000 running hours and renew if the rubbing tips have worn so as to reduce the depth to 2".

**TO INSPECT AND CHANGE THE BLADES**

For inspection of blades firstly remove the eyebolt (37) exposing a hole leading to the cylinder bore. Insert a measuring rod, rotate the shaft by hand so that the cone end is resting on the rotor diameter, scribe a mark on the rod at the level of the machine face. Turn the rotor until the point of the rod drops into the slot and rests on the blades tip, scribe a second mark, measure the difference between the marks. The blades must be changed if this dimension is greater than 1/8" (3mm). Replace the eyebolt.

To change the blades dismantle rear end by undoing two screws (24) and removing the oil pump (14) and oil pipes (35 & 36) and unscrew the lubricator extension (10). Remove fancover by undoing three set screws (29), the fan can be released by removing the screws (25). After removing six set screws (22) the coverplate (3) can be withdrawn with endcap (5) and outer race of roller bearing (16). **AT THIS STAGE MEASURE AND NOTE THE THICKNESS OF THE GASKETS FITTED BETWEEN THE CYLINDER AND COVERPLATE.** The blades can now be changed. When renewing blades make sure they slide freely in their slots and if necessary remove any high spots with emery cloth. Slightly smear all surfaces of the blades with oil before re-assembly.

**TO CHANGE BEARINGS AND SHAFT SEAL**

Proceed as above for changing blades, and then using a two-leg pulley drawer remove the inner race of the roller bearing from the shaft. The seal sleeve can now be removed.

To dismantle the drive end undo six coverplate screws (22) and withdraw coverplate and rotor/shaft assembly. **AGAIN NOTE THE THICKNESS OF THE GASKETS AT THIS END.** Take off drive endcap (4) and carefully note the position of the ballville washers (27) and shim (26), remove the circlip (39) and bearing retaining washer (9). Using a two leg pulley drawer remove the ball bearings (15), noting the position of the bearings before their removal. When both seal sleeves (6) are removed care must be taken not to interchange them as this will affect the clearances.

**TO RE-ASSEMBLE**

It is essential that all parts are perfectly clean before re-assembly. Ensure that the oilways in the coverplates are clear.

Lightly smear the shaft with grease to assist assembly.

Re-build with gaskets having exactly the same thickness as the originals.



The correct clearances are :-

|  |             |               |
|--|-------------|---------------|
| Between rotor and rear end coverplate :  | .009"/.010" | (.23mm/.25mm) |
| Between rotor and drive end coverplate : | .004"/.005" | (.10mm/.13mm) |
| Between rotor and cylinder bore :        | .004"/.005" | (.10mm/.13mm) |

Failure to follow the above instructions can cause seizure or loss of performance.


WHEN ORDERING SPARE PARTS ALWAYS QUOTE THE MACHINE SERIAL NUMBER.

C 178



| ITEM | DESCRIPTION              | PART NO. | NO. OFF |
|------|--------------------------|----------|---------|
| 1    | CYLINDER                 | S 8484   | 1       |
| 2    | COVERPLATE - DRIVE END   | S 8482   | 1       |
| 3    | COVERPLATE - REAR END    | S 8489   | 1       |
| 4    | END CAP - DRIVE END      | S 8491/2 | 1       |
| 5    | END CAP - REAR END       | S 8491/1 | 1       |
| 6    | SEAL SLEEVE              | S 8490   | 2       |
| 7    | ROTOR AND SHAFT ASSEMBLY | S 10025  | 1       |
| 8    | BLADE                    | S 8140/2 | 6       |
| 9    | BEARING RETAINING WASHER | S 8190   | 1       |
| 10   | LUBRICATOR EXTENSION     | S 10000  | 1       |
| 11   | GUARD                    | S 8496   | 1       |
| 12   | FAN                      | S 8487   | 1       |
| 13   | PUMP DRIVE EXTENSION     | S 8854   | 1       |
| 14   | BEKA OIL PUMP            | T 1014   | 1       |
| 15   | ANGULAR CONTACT BEARING  | H 1026   | 2       |
| 16   | ROLLER BEARING           | H 1036   | 1       |
| 17   | SHAFT SEAL               | F 1073   | 2       |
| 18   | OIL DRIP INDICATOR       | S 9193   | 1       |
| 19   | FAN                      | S 8185/1 | 1       |
| 20   | GASKET - COVERPLATE      | K 1119   | 2       |
| 21   | GASKET - END CAP         | K 1120   | 2       |

| ITEM | DESCRIPTION                   | PART NO. | NO. OFF |
|------|-------------------------------|----------|---------|
| 22   | HEX HEAD SCREW                | G 1083   | 12      |
| 23   | HEX HEAD SCREW                | G 1088   | 8       |
| 24   | SOCKET HEAD CAP SCREW         | Q 1121   | 2       |
| 25   | HEX HEAD SCREW                | Q 1094   | 1       |
| 26   | SHIM                          | K 1123   | 1       |
| 27   | BELLVILLE WASHER              | B 1127   | 2       |
| 28   | PLAIN WASHER                  | U 1025   | 3       |
| 29   | SET SCREW                     | G 1083   | 3       |
| 30   | HEX HEAD SCREW                | G 1075   | 3       |
| 31   | ELBOW                         | R 1061   | 1       |
| 32   | TUBING NUT                    | R 1040   | 3       |
| 33   | STEM ADAPTOR                  | S 8912/1 | 2       |
| 34   | NON-RETURN VALVE              | S 8956   | 2       |
| 35   | OIL DELIVERY PIPE - DRIVE END | X 1111   | 1       |
| 36   | OIL DELIVERY PIPE - REAR END  | X 1112   | 1       |
| 37   | EYE BOLT                      | A 1013   | 1       |
| 38   | GRUB SCREW                    | G 1032   | 1       |
| 39   | CIRCLIP                       | B 1012   | 1       |
| 40   | PLAIN WASHER                  | U 1026   | 3       |
| 41   | NUT                           | B 1000   | 3       |
| 42   | NUT                           | B 1049   | 1       |



| Item | Description            | Part No. |         | No. Off | Item | Description                   | Part No. |        | No. Off |
|------|------------------------|----------|---------|---------|------|-------------------------------|----------|--------|---------|
|      |                        | MDC72    | MDC124  |         |      |                               | MDC72    | MDC124 |         |
| 1    | CYLINDER               | S1743/1  | S1743/2 | 1       | 22   | GASKET (COVERPLATE)           | S1757    | S1757  | 2       |
| 2    | COVERPLATE             | S1841    | S1841   | 2       | 23   | GASKET (FLANGE)               | S1697    | S1697  | 2       |
| 3    | END CAP - DRIVE END    | S1839    | S1839   | 1       | 24   | STUD                          | S1822    | S1822  | 12      |
| 4    | END CAP - PUMP END     | S1840    | S1840   | 1       | 25   | NUT                           | B1044    | B1044  | 12      |
| 5    | ROTOR & SHAFT ASSEMBLY | S1735/1  | S1735/2 | 1       | 26   | WASHER                        | U1027    | U1027  | 12      |
| 6    | BLADE                  | S1568/1  | S1568/2 | 8       | 27   | SOCKET CAP HEAD SCREW         | G1116    | G1116  | 6       |
| 7    | SPACING RING           | S1516/5  | S1516/5 | 2       | 28   | SOCKET HEAD CAP SCREW         | G1121    | G1121  | 2       |
| 8    | COUPLING               | S1787    | S1787   | 1       | 29   | HEX. HEAD SCREW               | G1086    | G1086  | 8       |
| 9    | FLANGE                 | M1053    | M1053   | 2       | 30   | 'O' RING                      | F1120    | F1120  | 2       |
| 10   | SHORT STEM ADAPTOR     | S8912/1  | S8912/1 | 1       | 31   | PIN                           | E1022    | E1022  | 1       |
| 11   | LONG STEM ADAPTOR      | S8912/2  | S8912/2 | 1       | 32   | ADAPTOR                       | R1055    | R1055  | 2       |
| 12   | NON RETURN VALVE       | S8917/1  | S8917/1 | 2       | 33   | TUBING NUT                    | R1040    | R1040  | 8       |
| 13   | ROLLER BEARING         | H1031/H  | H1031/H | 1       | 34   | OIL DELIVERY PIPE - PUMP END  | X1082    | X1082  | 1       |
| 14   | BALL BEARING           | H1003/H  | H1003/H | 1       | 35   | OIL DELIVERY PIPE - DRIVE END | X1084    | X1084  | 1       |
| 15   | SHAFT SEAL             | F1151    | F1151   | 2       | 36   | HEX. REDUCING BUSH            | M1197    | M1197  | 1       |
| 16   | LOCK NUT               | B1052    | B1052   | 1       | 37   | HEX. REDUCING BUSH            | M1198    | M1198  | 1       |
| 17   | TAB WASHER             | B1004    | B1004   | 1       | 38   | DRAIN TAP                     | M1064    | M1064  | 1       |
| 18   | CIRCLIP                | B1013    | B1013   | 1       | 39   | BRACKET                       | S1525    | S1525  | 1       |
| 19   | BEARING SHIM           | K1133    | K1084   | 4       | 40   | OIL DRIP INDICATORS           | S1063    | S1063  | 2       |
| 20   | DOWEL                  | E1013    | E1012   | 4       | 41   | ELBOW                         | R1061    | R1061  | 2       |
| 21   | BEKA OIL PUMP          | T1013    | T1014   | 1       | 42   | OIL FEED PIPE                 | X1085    | X1085  | 2       |


#### OIL PUMP ADJUSTMENT

The oil pump is adjusted to the correct flow rate when despatched from our works. If it is found necessary to alter the oil feed, proceed as follows:—

Remove the cover (1) to expose the 2 pistons (2).

Slacken off the locknuts (3) and adjust the feed as required.

To increase the flow, turn the adjusting screws (4) clockwise or anti-clockwise to decrease.



## THE UTILE ENGINEERING CO. LTD.

IRTHLINGBOROUGH  
NORTHANTS, ENGLAND.  
Tel: (0933) 650216.  
Telex: 312198.

IC 067

## Operating Instructions for BEKA Lubrication Pump

### MAINTENANCE

Refill the oil tank regularly to ensure that the level is not allowed to fall to the point where air can be drawn into the pump. Use only clean new oil of the grade recommended in the instructions for the machine.


At least every year, or if the machine has been out of use for a long period, the pump must be thoroughly flushed with petrol/kerosene to clear any oil residues which may have solidified in the control ducts. To carry out this operation we recommend the following procedure.

- 1) Stop machine and disconnect oil feed pipe from tank.
- 2) Remove oil tank from cradle, drain oil, wash out with petrol/kerosene, drain again ensuring that all residues are removed, and replace. Reconnect feed pipe to pump.
- 3) Fill tank with sufficient petrol/kerosene to cover oil filter element. Loosen feed pipe connection at pump end until all air has been dispelled. Retighten pipe connection.
- 4) Start machine under no load conditions and run until petrol/kerosene begins to flow from oil pump discharge points. This operation will take approximately 15 minutes and providing that the machine is not on load no damage will occur.
- 5) Stop machine, drain oil tank and fill with recommended grade of oil. Ensure that oil pump feed pipe is primed. Reconnect delivery pipes and start up.

**NOTE.** The small amount of cleaning fluid left in the system will not damage the pump providing that it is run under no load conditions until the delivery pipelines have been cleared.

continued overleaf

# AR100bp



## Hosetail Options AR100

|        |                             | Part No. |
|--------|-----------------------------|----------|
| Inlet  | 30mm x 90° Hosetail (Liner) | 47580040 |
|        | + 1 1/4" BSP (F) Cap        | 47580060 |
|        | + 1 1/4" BSP Nipple         | 47580030 |
| Outlet | 1" x 90° Hosetail (Liner)   | 47550370 |
| OR     | 3/4" x 90° Hosetail (Liner) | 47550380 |
|        | + 1" BSP (F) Cap            | 47550242 |
|        | + 1" BSP Nipple             | 47550340 |

| Ref. | Description        | Qty | Part No. |
|------|--------------------|-----|----------|
| A 1  | O.R. Coupling Body | 1   | 47550250 |
| 2    | Torque Plate       | 1   | 47380271 |
| 3    | Nut 12MA           | 1   | 47320130 |
| 4    | Lock Washer        | 1   | 47320131 |
| 5    | Clamp              | 1   | 47500160 |
| 6    | Washer             | 1   | 47500171 |
| 7    | Bolt 12MA x 75     | 1   | 47320170 |
| 8    | Pin                | 2   | 47550290 |
| 9    | Stud 10MA x 34     | 2   | 47580020 |
| 10   | S Link             | 4   | 47650340 |
| 11   | Torque Chain       | 2   | 47320640 |
| 12   | Nut 10MA           | 2   | 47180150 |
| 13   | Spring Washer      | 2   | 47200231 |
| 14   | Wing Nut           | 1   | 47320610 |
| 15   | Washer             | 1   | 47320620 |
| 16   | Eye Bolt           | 1   | 47320630 |
| 17   | Pin                | 2   | 47550290 |
| 18   | Shaft Extension    | 1   | 47550260 |
| 19   | Pump Base          | 1   | 47580080 |
| 20   | Bolt 10MA x 30     | 1   | 47540300 |
| 21   | Nut 10MA x H10     | 1   | 47580190 |
| 22   | Screw              | 3   | 47620470 |
| 23   | Pulley 2B0 2A      | 1   | 47620280 |
| 24   | Pulley Bush        | 1   | 47550510 |
| 25   | Splined Shaft      | 1   | 47550173 |

|     |                      |    |          |
|-----|----------------------|----|----------|
| B 1 | Body                 | 1  | 47580010 |
| 2   | Manifold             | 1  | 47580150 |
| 3   | Cylinder Head        | 2  | 47550101 |
| 4   | Cylinder Head        | 1  | 47550102 |
| 5   | Nut 10MA             | 12 | 47180150 |
| 6   | Diaph. Retaining Nut | 3  | 47550131 |
| 7   | Retaining Plate      | 3  | 47580090 |
| ★ 8 | Diaphragm            | 3  | 47550085 |
| 9   | Piston Sleeve        | 3  | 47580110 |
| 10  | Piston Ring          | 3  | 47500260 |
| 11  | Stud                 | 3  | 47550270 |
| 12  | Piston               | 3  | 47580120 |
| 13  | Piston Spindle       | 3  | 47380300 |

## ★ = Items in Winter Overhaul Kit

|      |                         |    |          |
|------|-------------------------|----|----------|
| 14   | Circlip                 | 6  | 47380080 |
| 15   | Con Rod                 | 3  | 47580140 |
| ★ 16 | 'O' Ring                | 6  | 47320020 |
| ★ 17 | Valve                   | 6  | 47550050 |
| 18   | 1 1/4" BSP Hosetail Nut | 1  | 47580080 |
| 19   | 'O' Ring                | 2  | 47390291 |
| 20   | Hexagonal Nipple        | 1  | 47580030 |
| 21   | Nut 8MA H6.5            | 3  | 47390270 |
| 22   | Nut 10MA                | 3  | 47180150 |
| 23   | Gasket                  | 1  | 47580050 |
| 24   | Stud 10MA x 33          | 3  | 47280030 |
| 25   | Air Receiver Base       | 1  | 47580180 |
| 26   | Air Diaphragm           | 1  | 47550190 |
| 27   | Air Receiver Head       | 1  | 47550230 |
| 28   | Air Valve               | 1  | 47550300 |
| 29   | 'O' Ring                | 1  | 47650542 |
| 30   | Bolt 8MA x 30           | 4  | 47580290 |
| 31   | Circlip 62mm            | 1  | 47200391 |
| 32   | Seal Seat               | 1  | 47550470 |
| 33   | Washer                  | 1  | 47550070 |
| 34   | Needle Bearing          | 1  | 47550060 |
| 35   | Shaft                   | 1  | 47550170 |
| 36   | Spacer Ring             | 2  | 47580130 |
| 37   | Stud 10MA x 65          | 12 | 47550200 |
| 38   | Needle Bearing          | 1  | 47550310 |
| 39   | Stud 6MA x 34           | 2  | 47550330 |
| 40   | 'O' Ring                | 1  | 47180101 |
| 41   | Oil Reservoir           | 1  | 47550030 |
| 42   | Nut 6MA H6              | 2  | 47390440 |
| 43   | 'O' Ring                | 1  | 47550040 |
| 44   | Oil Reservoir Cap       | 1  | 47550050 |
| 45   | Nut 8MA                 | 4  | 47380240 |
| 46   | Hexagon Nipple          | 1  | 47550340 |
| 47   | 'O' Ring                | 1  | 47550350 |
| 48   | 25mm 90° Hosetail       | 1  | 47550370 |
| 49   | 1" BSP Hosetail Nut     | 1  | 47550242 |
| 50   | 30mm 90° Hosetail       | 1  | 47580040 |
| 51   | Stud 10MA x 72          | 3  | 47550020 |
| 52   | 'O' Ring                | 1  | 47250310 |
| 53   | Seal, Oil               | 1  | 47550491 |
| 54   | Seal                    | 1  | 47550480 |
| 55   | 3/4" BSP Plug           | 1  | 47030171 |
| 57   | Manifold Elbow (Right)  | 2  | 47580071 |
| 58   | Manifold Elbow (Left)   | 1  | 47580072 |
| 59   | P.T.O. Guard            | 1  | 47540660 |
| 60   | Washer                  | 1  | 47550331 |